

**PRO**<sup>®</sup>  
T701 Digital Non  
Programmable Thermostat



# PRO1 T701 Digital Non Programmable Thermostat Instruction Manual

[Home](#) » [PRO1](#) » PRO1 T701 Digital Non Programmable Thermostat Instruction Manual 

## Contents

- 1 [PRO1 T701 Digital Non Programmable Thermostat](#)
- 2 [Product Specifications](#)
- 3 [Product Usage Instructions](#)
  - 3.1 [Contact Us and Warranty Information](#)
- 4 [Frequently Asked Questions \(FAQ\)](#)
- 5 [Getting to know your thermostat](#)
- 6 [Battery door information](#)
- 7 [Easy to use controls](#)
- 8 [Contact Us Information](#)
- 9 [Warranty Registration](#)
- 10 [Documents / Resources](#)
  - 10.1 [References](#)
- 11 [Related Posts](#)



**PRO1 T701 Digital Non Programmable Thermostat**



## Product Specifications

- **Model:** Pro1 Thermostat
- **Power Source:** 2 AA Alkaline batteries
- **Display:** LCD
- **Warranty:** 5 year limited warranty

## Product Usage Instructions

### Thermostat Quick Reference:

To get to know your thermostat, familiarize yourself with the following components:

1. LCD Display
2. Glow in the Dark Light Button
3. Fan Switch
4. System Switch
5. Easy Change Battery Door
6. Temperature Setpoint Buttons

### How to Replace Batteries:

Use the finger bevel on the lower portion of the side of the thermostat to open the easy access battery door. Replace with 2 AA Alkaline batteries.

### Simple Operating Instructions:

Operating instructions are found on the back of the battery door for easy reference.

### THERMOSTAT OPERATION:

Follow these steps to operate your thermostat effectively:

1. **LCD Display:** Refer to page 2 of the manual for details about the display readout.
2. **Glow in the Dark Light Button:** This button illuminates the display when pressed.
3. **Fan Switch:** Choose between ON (fan runs continuously) or AUTO (fan cycles with heating/cooling).

4. **System Switch:** Select HEAT, COOL, or OFF mode for your HVAC system.
5. **Temperature Setpoint Buttons:** Use + or – buttons to set the desired room temperature.

## Contact Us and Warranty Information

### Contact Information:

If you need assistance, contact Pro1 at the following details:

- **Address:** 1111 S. Glenstone Suite 2-100 Springfield, MO 65804
- **Toll-free:** 1-888-Pro1iaq (776-1427)
- **Toll Number (Outside USA):** [330-821-3600](tel:330-821-3600)
- **Website:** <http://www.pro1iaq.com>
- **Hours of Operation:** Mon-Fri 9 AM – 6 PM Eastern

### Warranty Registration:

Your Pro1 thermostat comes with a 5-year limited warranty. Remember to register your warranty within 60 days of installation through one of the following methods:

1. Go to [www.pro1iaq.com](http://www.pro1iaq.com), select warranty registration, and fill out the form online.
2. Complete the warranty registration form and mail it to the provided address.

## Frequently Asked Questions (FAQ)

- **What should I do if the low battery indicator appears?**

Replace the AA batteries immediately to prevent your system from becoming inoperable. Failure to do so may affect your heating and cooling system.

- **How can I turn on the glow-in-the-dark light on my thermostat?**

The glow-in-the-dark light button will self-illuminate after exposure to ambient light. Press the button to turn on the display light.

- **How do I select the operation mode of my HVAC system?**


The System Switch on your thermostat allows you to choose between HEAT, COOL, or OFF modes for your heating and cooling system.

Congratulations on purchasing a new thermostat. This thermostat was designed to the highest reliability and ease of use standards. Thank you for choosing Pro1.


### Caution:

Equipment damage hazard Do not operate the cooling system if the outdoor temperature is below 50° F (10° C) to prevent possible compressor damage.

## Getting to know your thermostat



1. LCD




- 2. Glow in the Dark Light Button
- 3. Fan Switch
- 4. System Switch
- 5. Easy Change Battery Door
- 6. Temperature Setpoint Buttons

**Important:**


The low battery indicator is displayed when the AA battery power is low. If the user fails to replace the battery within 21 days, the thermostat display will only show the low battery indicator as a final warning before the thermostat becomes inoperable.

**Battery door information**

Use the finger bevel on the lower portion of the side of the thermostat to open the easy access battery door.



Replace with 2 AA Alkaline batteries.




Simple operating instructions are found on the back of the battery door.

## Easy to use controls

### Caution:

When the battery icon  appears replace your AA batteries immediately. Failure to do so may result in your heating & cooling system becoming inoperable.



### 1. LCD Display:

See page 2 for details about this display read out.

**2. Glow in the Dark Light Button:**

The glow in the dark light button will self illuminate for several hours after exposure to ambient light. This button turns on the display light when pressed.

**3. Fan Switch:**

Select ON or AUTO. ON will run the fan continuously. AUTO will cycle the fan on only when the heating or cooling system is on.

**4. System Switch:**

Selects the operation mode of your HVAC system. Selecting HEAT turns on the heat mode. Selecting COOL turns on the air conditioning mode. Selecting OFF turns both heating and cooling off.

**5. Temperature Setpoint Buttons:**

Press the + or – buttons to select the desired room temperature.

**Contact Us Information**

- Pro1 IAQ Inc.
- 1111 S. Glenstone
- Suite 2-100
- Springfield, MO 65804
- **Toll-free:** 1-888-Pro1iaq (776-1427)
- **Toll Number (Outside the USA):** [330-821-3600](tel:330-821-3600)
- **Web:** <http://www.pro1iaq.com>
- **Hours of Operation:** Monday – Friday 9 AM – 6 PM Eastern

**Warranty Registration**

Your new Pro1 thermostat has a 5 year limited warranty. You must register your warranty within 60 days of installation. You can register your new thermostat in 2 ways.

1. Go to [www.pro1iaq.com](http://www.pro1iaq.com), select warranty registration and fill out a short registration form.  
-or-
2. Complete the form below and mail it to the address shown.

**Pro1 IAQ Warranty Registration:**

**Name:** \_\_\_\_\_

**Address:** \_\_\_\_\_

**City:** \_\_\_\_\_

**State:** \_\_\_\_\_

**Zip:** \_\_\_\_\_

**Thermostat Model:** \_\_\_\_\_

**Date Installed:** \_\_\_\_\_

**Complete form and mail to:**

**Pro1 IAQ Inc.**  
1111 S. Glenstone  
Suite 2-100  
Springfield, MO 65804

## Documents / Resources

	<p><a href="#">PRO1 T701 Digital Non Programmable Thermostat</a> [pdf] Instruction Manual T701, T701 Digital Non Programmable Thermostat, T701, Digital Non Programmable Thermostat, Non Programmable Thermostat, Programmable Thermostat, Thermostat</p>
---	---

## References

- [Pro1 IAQ Thermostats - Non Programmable | Programmable | Wireless](#)
- [User Manual](#)

### Manuals+, [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.