



ProClip 522883 Non-Powered Cradle with Key Lock Installation Guide

[Home](#) » [ProClip](#) » ProClip 522883 Non-Powered Cradle with Key Lock Installation Guide 

Contents

- [1 ProClip 522883 Non-Powered Cradle with Key Lock](#)
- [2 Important:](#)
- [3 Returns](#)
- [4 Limited Warranty and Liabilities](#)
- [5 Documents / Resources](#)
 - [5.1 References](#)
- [6 Related Posts](#)



ProClip 522883 Non-Powered Cradle with Key Lock



Important:

Self-installation instructions and advice are provided for your convenience. It is your responsibility to determine if you have the knowledge, skills, and physical ability required to properly perform an installation. ProClip USA, Inc. shall have no liability for damage or injury resulting from the installation or use of any ProClip or third party products. It is your responsibility to ensure that all products are installed in adherence with local laws and regulations and in such a manner as to allow a vehicle to be operated safely and without distraction. ProClip USA,

Inc. product warranties do not cover the installation, removal or re-installation of any product.



Attention:

Carefully read all instructions and review the images before installing this product.

1. Place the cradle over the matching holes in the face plate of your mounting bracket (ProClip aluminum pedestal shown in picture) Attach the base plate by using the applicable bolts enclosed.



2. To place the device in the cradle: Place the lower part of the device in the cradle, then flip/press the upper part forwards so it snaps into place in the cradle. Slide the key lock into place and press the lock button to secure it.
3. To remove the tablet from the cradle: Open the lock using the enclosed key and slide the block up. Press upwards on the upper part of the cradle, in the same time pull the upper part of the device out from the cradle and then lift the device up and out from the cradle.
4. The cradle and tablet are in place. Switch between portrait and landscape view by rotating the cradle to desired position.

Returns

All returns must be made within thirty (30) days of the delivery date and include proof of purchase, a copy of your original order, or invoice. No products shipped hereunder may be returned without ProClip USA's prior approval. In order to return a product, the buyer must obtain an RMA number (Return Merchandise Authorization Number). Items returned without a valid RMA number may be rejected. Items that are open, used, damaged, or returned without all original components may have a restocking fee applied.


Limited Warranty and Liabilities

ProClip warrants that the Products will be free of defects in materials and workmanship for a period of one (1) year from the date of purchase. If any Product should become defective within the warranty period, ProClip, at its option, will replace it, repair it or refund the purchase price. Repair or replacement parts or Products will be furnished on an exchange basis and will either be new or reconditioned. All replaced Products shall become the property of ProClip. Warranty service is available to you by delivering the Product during the warranty period to the company it was purchased from or to ProClip at 4915 Voges Rd., Madison, WI 53718 USA and providing proof of purchase, price and date. If shipped to ProClip, the buyer must first call ProClip at +1 800-296-3212 or e-mail ProClip at returns@proclipusa.com to obtain a return approval and return number. You will bear all shipping, packaging and insurance costs and all other costs, excluding labor and parts, necessary to effectuate repair, replacement or refund under this warranty. For more information on how to obtain warranty service, write, e-mail

or telephone ProClip at 4915 Voges Rd., Madison, WI 53718 USA.Tel: +1 800-296-3212, e-mail: returns@proclipusa.com.

THIS LIMITED WARRANTY DOES NOT EXTEND TO ANY PRODUCT WHICH HAS BEEN DAMAGED AS A RESULT OF ACCIDENT, MISUSE, ABUSE OR AS A RESULT OF UNAUTHORIZED SERVICE. THIS WARRANTY IS IN LIEU OF ALL OTHER EXPRESS WARRANTIES FOR THIS PRODUCT. IMPLIED WARRANTIES, INCLUDING THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT SHALL HAVE NO GREATER DURATION THAN 1 YEAR FROM THE DATE OF PURCHASE. IN THE EVENT THIS PRODUCT BECOMES DEFECTIVE DURING THE WARRANTY PERIOD, THE PURCHASER'S EXCLUSIVE REMEDY SHALL BE REPAIR, REPLACEMENT OR REFUND AS PROVIDED ABOVE. IN NO EVENT SHALL PROCLIP BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES, INCLUDING WITHOUT LIMITATION LOSS OF PROPERTY, ARISING FROM BREACH OF ANY EXPRESSED OR IMPLIED WARRANTY. PROCLIP DISCLAIMS ALL WARRANTIES, EXPRESS OR IMPLIED, OTHER THAN THOSE SET FORTH ABOVE. IN NO EVENT WILL PROCLIP BE LIABLE TO YOU OR ANY THIRD PARTY FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES, INCLUDING, WITHOUT LIMITATION, INDIRECT, SPECIAL, PUNITIVE, OR EXEMPLARY DAMAGES, INCLUDING ATTORNEY FEES ARISING OUT OF THE USE OF OR THE INABILITY TO USE THE PRODUCTS, OR FOR ANY CLAIM BY ANY OTHER PARTY, EVEN IF PROCLIP HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.Regulatory information: www.proclipusa.com/regulatory.html

Documents / Resources

	ProClip 522883 Non-Powered Cradle with Key Lock [pdf] Installation Guide 522883, Non-Powered Cradle with Key Lock, 522883 Non-Powered Cradle with Key Lock
--	---

References

- usa.tel
- [ProClip USA | Car Phone Holders and Dashboard Phone Mounts](#)
- [Regulatory Information | ProClip USA](#)