



Progameplays PRO-T1 Phone Triggers Controller Instructions

[Home](#) » [Progameplays](#) » Progameplays PRO-T1 Phone Triggers Controller Instructions 

PROGAMEPLAYS



Instructions

Contents

- [1 Manual Pro Trigger for Gaming](#)
- [2 Documents / Resources](#)
 - [2.1 References](#)

Manual Pro Trigger for Gaming


Note: They are compatible with any mobile game, in this example we will configure the buttons in “Pubg Mobile” but the configuration is similar in other games .

1. Once the game is started, go to “Settings” then “Control” and then “Customize”.
2. Locate the “Fire” and “Aim” buttons and raise them to the top of the screen just below the PRO Trigger touchpad (See the image above for reference).

3. “Save the settings” and you will be able to enjoy your favourite game like a PRO!

Did you encounter any problems with your Triggers?
Please contact us, we are here to help you: info@progameplays.com

Documents / Resources

	<p>Progameplays PRO-T1 Phone Triggers Controller [pdf] Instructions PRO-T1 Phone Triggers Controller, PRO-T1, Phone Triggers Controller, Triggers, Controller</p>
---	---

References

- [User Manual](#)

[Manuals+.](#) [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.