



PROGRESS P300492-030-CS Captarent LED White Color Selectable Modern Mirror Installation Guide


[Home](#) » [PROGRESS](#) » PROGRESS P300492-030-CS Captarent LED White Color Selectable Modern Mirror Installation Guide 

Contents


- [1 PROGRESS P300492-030-CS Captarent LED White Color Selectable Modern Mirror](#)
- [2 PACKAGE CONTENTS](#)
- [3 HARDWARE CONTENTS](#)
- [4 Safety Information](#)
- [5 Preparation](#)
- [6 Care and Maintenance](#)
- [7 Assembly Instructions](#)
- [8 FCC STATEMENT](#)
- [9 CONTACT](#)
- [10 Documents / Resources](#)
 - [10.1 References](#)



PROGRESS P300492-030-CS Captarent LED White Color Selectable Modern Mirror



Models



P300470




P300492



P300493






PACKAGE CONTENTS

PART	DESCRIPTION	QUANTITY
A	Mirror Frame	1
B	Template	1



HARDWARE CONTENTS

HARDWARE CONTENTS (not actual size)

<p>AA</p>  <p>Pan Head Self Tapping Screw Qty:10 (P300470, P300492) Qty:12 (P300493)</p>	<p>BB</p>  <p>Wall Anchors Qty:10</p>	<p>CC</p>  <p>Wire Nut Qty:3</p>	<p>DD</p>  <p>Mounting Bracket Qty:2 (P300470) Qty:4 (P300492, P300493)</p>	<p>EE</p>  <p>Locking Bracket Qty:2</p>
---	--	---	---	--

Safety Information

- Please read and understand this entire manual before attempting to assemble, operate or install the product.
- **CAUTION:** Read instructions carefully and turn the electricity off at the main circuit breaker panel before beginning installation.
- **CAUTION:** Risk of fire. Min. 90°C supply conductors. Consult a qualified electrician to ensure the correct

branch circuit conductor.

- **WARNING:** If any Special Control Devices are used with this fixture, follow instructions carefully to ensure full compliance with
- N.E.C. requirements. If there are any questions, contact a qualified electrical contractor.
- **CAUTION:** All glass is fragile. Use care when handling glass shades and bulbs.
- THIS PRODUCT MUST BE INSTALLED BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE
- PRODUCT AND THE HAZARDS INVOLVED, UNDER THE APPLICABLE INSTALLATION CODE.
- KEEP THESE INSTALLATION INSTRUCTIONS

Preparation


1. Before beginning installation, make sure all parts are included using the contents diagrams from page 1. If any part is missing or damaged, do not attempt to assemble, install or operate the product.
2. Estimated assembly time: 30 minutes.
3. Tools required for assembly (not included): screwdriver, pliers, wire stripper, safety glasses, electrical tape, ladder, and drill.\

Care and Maintenance

- Shut off the main power supply before cleaning products or changing light bulbs.
- To clean, wipe with a damp cloth. Do not use abrasive cleaners or cleaners that contain alcohol.

Assembly Instructions


1. Place the mounting template (B) against the wall and mark the position of the screw holes on the wall.



2. For hole locations in drywall with no wood studs, use a 3/8 inch (9.5mm) drill bit to drill pilot holes into the wall

at the template locations marked. Then insert the wall anchors (BB) into the pilot holes.

For hole locations directly on a wood stud, use a 1/16 inch (1.6mm) drill bit to drill pilot holes in the wall at the template locations marked. Screw the pan head self-tapping screws (AA) through the mounting brackets (DD) and into the wall anchors (BB) or wood studs.



NOTE: Wall anchors are required for use in drywall hole locations with no wood stud access. For any pilot holes drilled directly into a wooden stud, the wall anchors are not required.

Note: Ensure that the mounting brackets (DD) are level.

Note: For P300492/P300493, be sure to use the two shorter brackets for vertical mounting and the two longer brackets for horizontal mounting.


3. Install an NM cable connector clamp (not included) into the mounting plate (not included).

Pass the mirror jumper wire through the clamp and secure it.

Strip 3/8" of insulation from the electrical wire ends. Using wire nuts (CC), connect the WHITE fixture wire to the WHITE supply wire from the outlet box; connect the BLACK fixture wire to the BLACK supply wire from the outlet box.


Connect the fixture ground wire and supply ground wire using a wire nut or by fastening it to the ground screw on the swivel mounting strap. Push all of the wire connections carefully into the outlet box.

Install this assembly to the junction box using the mounting screws supplied with the junction box (not included).




4. Hang the mirror (A) onto the mounting brackets (DD).

WARNING: Be careful to make sure that the mirror is properly seated on the mounting brackets before fully letting go of the mirror.




5. Install the two locking brackets (EE) right above the top of the mirror frame. Use a 3/8-inch drill bit to drill pilot holes and insert the wall anchors (BB).
Screw the two pan head self-tapping screws (AA) through the locking brackets (EE) and into the two wall anchors (BB).



Touch Button Functionality

- Short press turns the light on and off
- Press and Hold adjusts the brightness level
- Short press cycles through 3 different CCT levels



FCC STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, under part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used under the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help.


Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

CONTACT

- [800-447-0573](tel:800-447-0573)
- 8 am-8 pm (Eastern), Monday-Friday
- customerservice@progresslighting.com

For warranty information, please refer to <https://www.hubbell.com/progresslighting/en/warranty>

Documents / Resources



[PROGRESS P300492-030-CS Captarent LED White Color Selectable Modern Mirror](#) [pdf] Installation Guide
P300492-030-CS Captarent LED White Color Selectable Modern Mirror, P300492-030-CS, Captarent LED White Color Selectable Modern Mirror, White Color Selectable Modern Mirror, Selectable Modern Mirror, Modern Mirror

References

- [User Manual](#)

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.