



Projectors Projector Wireless Connection User Manual

[Home](#) » [Projectors](#) » Projectors Projector Wireless Connection User Manual 

Contents

- [1 Projectors Projector Wireless Connection](#)
- [2 Projector wireless connection manual](#)
- [3 Projector disconnects wireless connection manual](#)
- [4 Documents / Resources](#)
- [5 Related Posts](#)


Projector

Projectors Projector Wireless Connection




Projector wireless connection manual

1. Turn on the projector and select the wireless connection option.




2. Enter the blue interface, and then follow the instructions to connect wirelessly. The IP code in the picture is the network IP address of the projector, and DEVICE is the WIFI of the projector.


iPhone / Android / MacBook, etc. can be set according to this method



3. Search the WIFI of the projector in the mobile phone/computer and connect it.



4. "no internet" is usually displayed after connection, you can proceed without paying attention.



5. Log in to any browser on your phone/computer, enter the projector's network IP address and log in.


2:26

4G+ 1X 44%




Log in to the projector network IP in any browser on your computer/mobile phone

6. Select "WIFI AP".



7. Select the WIFI used in your home and enter the password.



AP Information

BSSID:
94:3b:b0:e7:eb:3c

Frequency:
2422Mhz

Security:
[WPA-PSK-CCMP][WPA2-PSK-CCMP][ESS]


Enter your WIFI password here and click connect

Password:


ASCII ☒ HEX ☐

Connect

8. When the name of the WIFI you are using is displayed in the upper right corner of the blue interface of the projector, it means that the projector has successfully connected to the WIFI.





9. Turn on the projection screen function on the mobile phone/computer, find and select your projector.



10. The wireless connection is successful and the setting is complete.

Projector disconnects wireless connection manual

1. Turn on the projector and run it to the blue interface.



2. Log in to the browser, enter the IP displayed in the upper left corner of the blue interface.




Enter the projector IP in the browser and log in


3. Click "WiFi AP".




4. Click “Forget” to forgot your WiFi.



5. If your WiFi name disappears in the upper right corner of the blue interface, it means that you have successfully disconnected the projector from the WiFi and the setup is complete.



Documents / Resources

	<p>Projectors Projector Wireless Connection [pdf] User Manual Projector Wireless Connection</p>
--	---