



[Home](#) » [ProtoArc](#) » **ProtoArc XKM01,XKM01-M Foldable Full Size Wireless Keyboard and Mouse**
User Manual 

Contents [[hide](#)]


- [1 ProtoArc XKM01,XKM01-M Foldable Full-Size Wireless Keyboard and Mouse](#)
- [2 Product Features](#)
- [3 2.4G Connection](#)
- [4 Bluetooth Connection](#)
- [5 Mouse Mode Switch Method](#)
- [6 Multimedia Function Keys](#)
- [7 How to Use Special Characters in British English](#)
- [8 Product Parameters](#)
- [9 Packing List](#)
- [10 Safety Warning](#)
- [11 FCC Statement](#)
- [12 Documents / Resources](#)
 - [12.1 References](#)







ProtoArc XKM01,XKM01-M Foldable Full-Size Wireless Keyboard and Mouse



Product Features






- A Left Button
- B Right Button
- C Scroll Wheel Button
- D DPI Switch Button
- E Charging / Low Battery Indicator Light

- F Type-C Charging Port
- G Bluetooth 2 Indicator Light
- H Bluetooth 1 Indicator Light
- I USB Indicator Light
- J Channel Switch Button
- K Power Switch
- L USB Receiver

2.4G Connection



1. Turn the power switch to ON.

1. Unfold the Keyboard.



2. Take out the USB receiver.



3. Plug into the computer's USB port.



4. Press the channel switch button until the  light is on, the mouse enters into 2.4G USB channel.

1. Single press  channel button, and the indicator light flashes slowly, enter


into 2.4G USB channel.



Bluetooth Connection

1. Turn the power switch to ON.

1. Unfold the Keyboard.






1. Turn the power switch to ON.




1. Unfold the Keyboard.

2. Press the channel switch button until the ***1 / *2** indicator light is on, the mouse enters the Bluetooth channel. Long press the channel switch button for 3-5 seconds again, until the ***1 / *2** light flashes quickly, then the mouse enters the Bluetooth pairing mode.




1. Single press  /  channel button, and the indicator light flashes once to enter the Bluetooth channel. Long press this Bluetooth channel button for 3-5 seconds again, the indicator light flashes quickly, then the keyboard enters into the Bluetooth pairing mode.



3. Turn on the Bluetooth settings on your device, search or select “ProtoArc XKM01” and start Bluetooth pairing until the connection is completed.

Charging Guide

1. When low power, the indicator light will turn red and flash quickly.
2. Insert the Type-C port into the mouse or keyboard and the USB-A port into the computer to charge, the red light stays on while charging.
3. The indicator light turns in green when fully charged.



Notice:


If the mouse or keyboard is low battery, there will be delays, freezes and other problems. Please connect to the power supply for charging in a timely manner to ensure that the mouse or keyboard has sufficient battery power to get normal performance.

Mouse Mode Switch Method



After are connected, short press Mode Switch Button on the bottom of the mouse, easily switch between multiple devices.

Bluetooth 1 Device Connection




Keyboard Mode Switch Method



















After are connected, short press the channel key on the keyboard, easily switch between multiple devices.

Bluetooth 1 Device Connection



Multimedia Function Keys











Keys	Windows OS	Android OS	iOS	Mac OS
	Light -	Light -	Light -	Light -
	Light +	Light +	Light +	Light +
	Window Switch	Window Switch	/	Window Switch
	Application Switch	Application Switch	Open latest Window	Open latest Window
	Display Desktop	Go Home	Go Home	Go Home
	Search	Search	Search	/
	Previous Track	Previous Track	Previous Track	Previous Track
	Play & Pause	Play & Pause	Play & Pause	Play & Pause
	Next Track	Next Track	Next Track	Next Track
	Mute	Mute	Mute	Mute
	Volume -	Volume -	Volume -	Volume -
	Volume +	Volume +	Volume +	Volume +
	Setup	/	/	/
	Lock Screen	Lock Screen	Lock Screen	/
	Screenshot	Screenshot	Screenshot	Screenshot
	FN+ESC (FN lock) button to turn on or turn off the FN function			


Note: The FN function is a cyclic mode (F1-F12 and multimedia functions are cyclically used).











How to Use Special Characters in British English


On MacOS/iPadOS/iOS system:

Press the key and you can type the symbol shows in the right square frame.








Press and hold the key "  ", then press the corresponding key, you can type the symbol shows in the right square frame.


			
			
			







Press and hold the key "  ", then press the corresponding key, you can type the symbol shows in the right square frame


	
-------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------




Press the key and you can type the symbol shows in the right square frame.

			2
	#		/
			

Press and hold the key "  ", then press the corresponding key, you can type the symbol shows in the right square frame.

			//
			@

			
-----------------------------------------------------------------------------------	--	--	--

Press and hold the key "  " (the key on the right side of the keyboard), then press the corresponding key, you can type the symbol " ¡ " and " € ".			
	¡		€

Product Parameters

Keyboard Parameters:

Battery Capacity	210 mAh
Working Current	≤ 3.5 mA
Sleep Current	31 uA
Charging Current	190 mA (±20mA)
Standby Current	≤ 0.3 mA
Standby Time	≥ 150 Days
Charging Time	< 2 Hours
Wake Up Way	Press any key
Weight	297 g
Keyboard Dimension	386.4x119.7x12.4mm(Unfolded) 215.5x119.7x20.9mm(Folded)

Mouse Parameters:

Engine	Optics
DPI	1000/1600/2400 DPI
Mouse Button Life	More than 3 million times
Battery Capacity	300mAh
Battery Life	1000 times charge and discharge cycles
Standby Time	200 Days
Continuous Working Time	50 hours
Mouse Dimensions	107.9*59.1*20.1mm

2.4G Transmission Parameters:

Transmission Distance	10m
Working Voltage	3.7V
Working Current	<5mA
Polling Rate	250Hz
System Requirements	An available USB port Windows XP, Windows 7, Windows 8, Windows 10 or higher version Mac OS X 10.10 or higher version

Bluetooth Transmission Parameters:

Transmission Distance	10m
Working Voltage	3.7V
Working Current	<5mA
Polling Rate	125Hz
System Requirements	Bluetooth receiving device Windows 8, Windows 10 or higher version Mac OS X 10.10 or higher version Android 4.3 or higher version

Tips

1. If Bluetooth connection is not working properly, fold the keyboard to turn off its power, then unfold the keyboard again to restart the device's Bluetooth and attempt to reconnect. Or delete the extra Bluetooth option name in the Bluetooth connection list

of the device and reconnect.

2. To switch to a successfully connected channel, press the channel button and wait for 3 seconds before continuing to use.
3. The keyboard and mouse have a memory function. When they are connected on a specific channel, turn off the keyboard and mouse and turn on again, they will automatically connect to the default channel and this channel indicator is on.

Sleep Mode

1. When the keyboard is not used for more than 30 minutes, it will automatically enter the sleep mode and the indicator light will be off.
2. When you use the keyboard again, you only need to press any key, and the keyboard will wake up within 3 seconds. The indicator will light up again and starts to work.

Packing List

- 1* Wireless Bluetooth Keyboard
- 1* Wireless Bluetooth Mouse
- 1* Type-C Charging Cable
- 1* Hard Carrying Case
- 1* Phone Holder
- 1* User Manual

Safety Warning

IMPORTANT: To reduce risk of fire, electric shock, or injury, follow these safety instructions.

- **Charging Safely:** Use only the provided cable. Charge in a well-ventilated, dry area away from inflammable materials.
- **Battery Handling:** Do not attempt to replace the item's lithium battery. Battery replacement should be conducted by qualified personnel to prevent hazards.
- **Heat Exposure:** Avoid leaving the item in high-temperature environments or in direct sunlight, which could result in a fire hazard.
- **Liquid Exposure:** Keep the item away from water and liquids. Do not use if wet until

thoroughly dried.

- **Damage and Leakage:** Cease usage and consult customer service if the item is damaged or the battery leaks.
- **Correct Disposal:** Follow local regulations for disposing of electronic devices and batteries. Do not dispose of with household waste.
- **Radio Frequency Interference:** This device may cause interference with other electronics. Keep a safe distance from sensitive devices.
- **Child Safety:** Keep the item and its components out of reach of children to void choking or battery ingestion hazards. Never allow children to handle the item unsupervised.

CAUTION: Non-compliance with the above warnings can lead to serious injury or property damage. For further assistance or information, please contact our customer service. Emergency Contact: +1 [886-287-6188](tel:886-287-6188) (United States)

EU Declaration of Conformity

Declared Object:	Foldable Full-Size Wireless Keyboard and Mouse Combo				
Model:	XKM01				
Rating:	3.7V \pm 10mA				
Input:	5V \pm 250mA				
Place of Production:	Made in China				
Manufacturer:	Shenzhen Hangshi Electronic Technology Co., LTD				
Email:	chen.zhao@bow.cn				
Address:	Floor 2, Building A1, Zone G, Democratic West Industrial Zone, Democratic Community, Shajing Street, Bao'an District, Shenzhen City, Guangdong Province, China, 518104				
European Representative:	<table border="1"><tr><td>EC</td><td>REP</td></tr></table> <p>Business name: g.L.L. GmbH Business address: Bauernvogtkoppel, 55c, 22393, Hamburg, Germany Email: g.L.L.DE@outlook.com Tel: +49 162 3305764</p> <table border="1"><tr><td>UK</td><td>REP</td></tr></table> <p>Business name: AMANTO INTERNATIONAL TRADE LIMITED Business address: The Imperial, 31-33 St Stephens Gardens, Notting Hill, London, United Kingdom, W2 5NA Email: AmantoUK@outlook.com Tel: +44 7921 801 942</p>	EC	REP	UK	REP
EC	REP				
UK	REP				

It is our sole responsibility to declare that the above products are in full compliance with

Directive 2014/53/EU, 2011/65/EU (as amended)

Position:

Managing Director

Signature:

ZHAO CHEN

Date of Sign:

2022.1.5

EU agent name:

Tong Jia

Date of Sign:

2022.1.5



FCC Statement

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur

in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

IC Warning


This device complies with Innovation, Science and Economic Development Canada's licence-exempt RSS standard(s). Operation is subject to the following two conditions:

1. This device may not cause interference; and
2. This device must accept any interference, including interference that may cause undesired operation of the device.

This Class B digital apparatus complies with Canadian ICES-003.

The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction.

Documents / Resources

	<p>ProtoArc XKM01,XKM01-M Foldable Full Size Wireless Keyboard and Mouse [pdf] User Manual</p> <p>XKM01 Foldable Full Size Wireless Keyboard and Mouse, XKM01-M, XKM01-M Foldable Full Size Wireless Keyboard and Mouse, Foldable Full Size Wireless Keyboard and Mouse, Full Size Wireless Keyboard and Mouse, Wireless Keyboard and Mouse, Keyboard and Mouse, Mouse</p>
-----------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

References

- [User Manual](#)

ProtoArc

Foldable Full Size Wireless Keyboard and Mouse, Full Size Wireless Keyboard and Mouse, Keyboard and Mouse, mouse, ProtoArc, Wireless Keyboard and Mouse, XKM01 Foldable Full Size Wireless Keyboard and Mouse, XKM01-M, XKM01-M Foldable Full Size Wireless Keyboard and Mouse

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.