



Contents [[hide](#)]

- [1 ProX Art Deco Click Pen Kit](#)
- [2 Specifications](#)
- [3 Product Usage Instructions](#)
- [4 REQUIRED ACCESSORIES](#)
- [5 PREPARING THE BLANKS](#)
- [6 TURNING THE BLANK](#)
- [7 ASSEMBLY](#)
- [8 Frequently Asked Questions](#)
- [9 Documents / Resources](#)
 - [9.1 References](#)



ProX Art Deco Click Pen Kit



Specifications

- Product Name: ProX Art Deco Click Pen Kit
- Model: Art Deco
- Pen Type: Click Pen

Product Usage Instructions

Required Accessories:

Before starting, ensure that you have the following accessories:

- ProX Art Deco Click Pen Kit
- Turning tools
- Sandpaper
- Finishing materials

Preparing the Blanks:

Prepare the pen blanks by cutting them to the desired length and drilling a hole through the center for the pen components.

Turning the Blank:

Mount the prepared blank onto your lathe and carefully shape it using turning tools. Ensure a smooth and even finish before proceeding.

Assembly:

Assemble the pen components according to the kit instructions. Insert the refill, cap, and click mechanism securely to complete the assembly process.

ProX Art Deco Click Pen Kit Instructions


REQUIRED ACCESSORIES

- 7mm Pen Mandrel
- 3/8" Drill Bit
- 2-piece ProX bushing set
- Barrel Trimming set (3/8" Sleeve)
- 2-part epoxy glue or Insta-Cure (cyanoacrylate) glue

PREPARING THE BLANKS

- Cut a blank to the length of the tube and add 1/16" for squaring off.
- Drill 3/8" center hole lengthwise through the blank.
- Glue the brass tube in the blank. Spread the glue on the tube. Insert into the blank with a twisting motion to spread the glue evenly inside. Center the tube lengthwise in the blank. Allow it to dry.
- After the glue dries, use a 3/8" Barrel Trimmer to square the ends of the blank flush with the ends of the brass tube

DIAGRAM B – TURNING THE BLANK



TURNING THE BLANK

- Place spacer bushings onto the pen mandrel. Slide an end bushing onto the mandrel, wide end first. Insert the blank and follow with the second bushing (narrow end first). Add additional spacer bushings to close the space to the threads on the mandrel. Thread the lock nut onto the mandrel hand-tight. Bring the tailstock in snug with the mandrel. Do not overtighten – this could damage the pen mandrel. Lock the nut and the tailstock in place.
- Turn the blanks down close to the bushings located at the ends of the blanks. Sand the blanks down to the bushings.
- Finish the barrel with your choice of polish. Allow sufficient time for the polish to cure. Refer to Polish instructions.

DIAGRAM A



ASSEMBLY

- Unscrew the tip assembly from the tip and the tip holder.
- Press the Tip holder into one end of the Tube.
- Insert the clip and ring into the end cap, clip first, ring next.
- Press the clip assembly into the other end of the Tube.
- Slide the Click mechanism from the tip holder into the clip assembly
- Insert the refill with the Spring into the open end of the tip holder. Note: Make sure the Refill goes through the tube end to show the click mechanism.
- Thread the tip onto the tip holder.
- Thread the click spring and the plunger onto the end of the clip assembly.

Note: Do not over-tighten the assembly onto the click Mechanism. To advance the refill, press the end of the click mechanism; to retract the refill, press the end of the click mechanism again.

Frequently Asked Questions


• Q: Can I use any type of wood for the pen blanks?

A: It is recommended to use hardwoods such as maple, walnut, or rosewood for better results.

• Q: How do I replace the refill in the pen?

A: To replace the refill, unscrew the pen tip, remove the old refill, and insert a new one of the same size and type.

Documents / Resources



[ProX Art Deco Click Pen Kit \[pdf\]](#) Instructions

Art Deco Click Pen Kit, Deco Click Pen Kit, Click Pen Kit, Pen Kit, Kit

References

- [User Manual](#)

Art Deco Click Pen Kit, Click Pen Kit, Deco Click Pen Kit, Kit, Pen Kit,

Prox PROX

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.