



ProXtend Windows Camera App Instructions

[Home](#) » [proxtend](#) » ProXtend Windows Camera App Instructions 

ProXtend Windows Camera App Instructions




Contents

- [1 How to access your webcam settings](#)
- [2 Documents / Resources](#)
- [3 Related Posts](#)


How to access your webcam settings


1. Plug your webcam into a USB port on your PC.
2. Locate the Microsoft camera application in the Windows start menu.




3. If your laptop (with built-in webcam) sits closed in dock and you use a stand-alone webcam on your external monitor, click the “Switch camera”-icon in the top right corner of your screen.



4. Now you have access to the stand-alone webcam and can adjust the settings from the  icon in the top left corner of the camera app.





Manuals+,