



PXN F16 Game Controller User Manual

[Home](#) » [PXN](#) » PXN F16 Game Controller User Manual 

PXN F16 Game Controller User Manual



Contents

- [1 System Requirements](#)
- [2 Product Overview](#)
- [3 Connect with PC](#)
- [4 Attention](#)
- [5 Product Specifications](#)
- [6 Documents / Resources](#)
- [7 Related Posts](#)

System Requirements

Compatible Platforms: PC

System Requirement on PC: Windows XP/7/8/10/11

Product Overview

Rapid-Fire Trigger

8-Way Hat Switch

Programmable Buttons

Direction Control

Throttle Valve

Vibration Switch

Anti-slip Silicone

Connect with PC


Step 1: Plug the joystick into PC USB port, the computer will prompt new hardware and install automatically.

Step 2: Function testing is available on the computer. The specific steps show below :

WIN 7/8: Open Control Panel → Device and Printer → Right mouse click PXN-F16 icon → Game Controller Setting, click Properties Testing.

WIN 10: Open Setting → Devices → Device and Printer → Right mouse click PXN-F16 icon → Game Controller Setting, click Properties Testing

Step 3: After entered testing screen(show below), you can test every axes and buttons function.



Attention

- Avoid strong vibration, don't disassemble or repair on your own.
- Don't keep in humid conditions, high temperature or a dusty location.
- Avoid getting water or other liquids into product.
- Please handle gently when connecting and removing product.
- Children should be under parent's supervision to use the product.

Product Specifications

- **Product Model:** PXN-F16
- **Connection Type:** USB Wiring
- **Power source:** DC 5V
- **Working Current:** 20mA-100mA
- **Packaging Size:** Appro. 215 * 195 * 235 mm
- **Product Size:** Appro. 200 * 190 * 220 mm
- **Unit Weight:** Appro. 517g
- **Usage Temperature:** 10 – 40 °C
- **Usage Humidity:** 20 ~ 80 %



Documents / Resources



[PXN F16 Game Controller](#) [pdf] User Manual
F16 Game Controller, F16, Game Controller, Controller