



PYLE PBMSPG1BK Bluetooth BoomBox Speaker System User Guide

[Home](#) » [Pyle](#) » PYLE PBMSPG1BK Bluetooth BoomBox Speaker System User Guide 

Contents

- [1 PYLE PBMSPG1BK Bluetooth BoomBox Speaker System User Guide](#)
- [2 Specifications](#)
- [3 Introduction](#)
- [4 What's In the Box?](#)
- [5 FEATURES](#)
- [6 INSTRUCTION](#)
- [7 Wireless BT Streaming](#)
- [8 FM Radio](#)
- [9 TWS Function](#)
- [10 How to charge](#)
- [11 Frequently Asked Questions](#)
- [12 Read More About This Manual & Download PDF:](#)
- [13 Documents / Resources](#)
 - [13.1 References](#)
- [14 Related Posts](#)

PYLE PBMSPG1BK Bluetooth BoomBox Speaker System User Guide



Specifications

- **Product Dimensions**

11.7 x 5 x 6 inches

- **Item Weight**

3.16 pounds

- **Connectivity Technology**

Bluetooth, Auxiliary, USB

- **Speaker Type**

Outdoor, Tweeter

- **Recommended Uses For Product**

For Surround Sound Systems

- **Brand**

Pyle

Introduction

The Bluetooth wireless boombox speaker has a 4" tweeter with 200 watts of peak output and 100 watts of RMS power at 4 ohm for full-range surround stereo sound reproduction. It also has a ported shell for deeper bass. With Bluetooth for wireless audio streaming, this boom box wireless Bluetooth speaker tube is compatible with gadgets including iPhones, Android phones, and iPad tablets. Perfect for personal indoor, outdoor, and residential use

What's In the Box?


- Portable Bluetooth Speaker
- USB Charging Cable
- Audio (3.5mm) Connection Cable
- User Manual

FEATURES

- Compact Boom Box Stereo Style
- Portable Travel-Friendly Speaker Design

- Digital Streaming FM Radio
- Built-in Rechargeable Battery
- MP3 Digital Audio File Playback
- Ported Enclosure for Extended Bass
- Full Range Stereo Sound Reproduction
- Rugged & Durable 'Super Tube' Speaker Housing

INSTRUCTION



1. Power ON/OFF
2. Play/Pause
3. MODE (Wireless BT Switch, USB disk, FM and AUX-IN state)
4. Backward/Volume down
5. Forward/Volume Up
6. USB port
7. Micro SD slot
8. Charging Jack
9. AUX IN

Wireless BT Streaming

1. Turn the power button to "ON", then you will hear a "Bluetooth Device Ready To Pair" tone. The LED light blinks quickly. The speaker is now in pairing mode.
2. Activate Wireless BT of your mobile phone and search for the device name "PyleUSA" then connect it. Once paired successfully, the Blue LED will blink slowly, and you will hear a tone "Bluetooth Device Connected Successfully" once connected.
3. Play the music from your mobile phone and enjoy.
4. Press the Forward or Backward button on the device or on Mobile phones to select songs you like.
5. Press Play/Pause button on the device or on Mobile phones to play/pause the music.
6. Press and hold the Forward or Backward button to adjust volume up and down or adjust the mobile phone's volume.

Playing music from USB disk & Micro SD card

1. Turn the Power button to “ON”.
2. Insert a Micro SD card or USB flash disk into the slot, the speaker will make a tone “Music Play Mode”, and play the stored music automatically.
3. Under playing mode, short press the Forward or Backward button to select songs you like, and press and hold to adjust the volume up and down.
4. Press Play/Pause to play or pause.

Remark

Under Wireless BT playing mode, insert Micro SD or USB will disconnect the Bluetooth and switch to play the USB or Micro SD card. You can press the MODE button to switch to Wireless BT mode again.

FM Radio

1. Under FM radio state, the audio cable provided is the antenna. Please insert the audio cable to get the best FM signal before using it.
2. Turn the power button to “ON”, and press the “MODE” button, the speaker will prompt “The Radio Mode” when entering the FM state.
3. Under playing mode, short press the “Play/Pause” button to auto search the FM Channel and store it automatically.
4. Press the Forward or Backward button to change the stored FM channel.

TWS Function

1. Turn ON two identical speakers you want to pair, please be noted that they must have the same BT pairing name, both under BT mode. You only need to set up one of the two units;
2. Press and hold the “PLAY/PAUSE” button for around 4 seconds, speaker will make a tone “di” to start pairing, and will make “di” voice 3 times once successfully paired;
3. Connect Wireless BT with your mobile phone to play music by the two paired Speakers to create a more powerful surround sound effect.
4. If you want to exit the TWS mode, press and hold “TWS” button (of the unit that you set at the beginning) again to exit the TWS function.

Remark

You can connect the TWS function through either Wireless BT or AUX, but if you connect your mobile phone via the provided audio cable, you can not switch to Wireless BT mode by pressing the Mode button.

AUX-IN

For other compatible music devices or your MP3/MP4 players, use the supplied audio line cable to connect from the device’s “Line Out” to the “Aux In” of this device. You would hear the “Aux input mode” tone once the cord is inserted. When using an external device, all functions can be controlled by the external device except pause.

Remarks

1. To turn the unit ON, press and hold the Power button for 3 seconds;
2. Press the MODE button to switch for different modes, the order is Wireless BT, USB disk, Micro SD, FM radio, and AUX-IN.

3. The default volume is at 50% status of max volume;
4. Turn the power button to “off” if not in use.

How to charge

1. The charger is not included in the accessories. Please use the Universal 5V/1A charger to charge this device, and we are not responsible for any damage caused by using another charger.
2. Power off the unit put the provided charge cable into the charging slot of the unit, and connect the other end to your PC or another charger with 5V output.
3. Charging time should be 3-5 hours. The light is red while charging, and the indicator light will switch off when fully charged. (When playing music during charging, please put the volume to the middle, because for some music with heavy bass, the charger may not be able to afford the high current temporarily under the maximum volume.)
4. In order to prolong the life of the battery, please do not charge for more than 8 hours.

Questions? Issues?

We are here to help!

Phone: (1) 718-535-1800 Email: support@pyleusa.com

Warning

This product can expose you to a chemical or group of chemicals, which may include “Cadmium (Cd)” which is known in the state of California to cause cancer, birth defects, or other reproductive harm. For more info, go to <https://www.p65warnings.ca.gov>

Frequently Asked Questions

• What’s the size in length of this radio?

Hi, the Total Speaker Size (L x W x H): 11.7” x 5.0” x 5.6” -inches. For more info, kindly visit our website pyleaudio.com. Type the model number on the search box PBMSPG1BK. Thank you

• How do we turn the volume up on the boombox?

Had the same problem when I received mine at first. You need to press the “+” button till you get to max then you can use the Volume control on your Bluetooth device.

• I can only pick up 3-5 FM stations and I’m in the suburbs. is this normal?

The unit will detect all the available frequencies near you. If you’re having a hard time getting stations, please try to place the unit in an open area and then scan available frequencies again. If the troubleshooting didn’t work kindly call our Technical Support Department at 718 535 1800 Press 2 then 1 from Monday to Friday 9 AM to 5 PM EST.

• When playing via SD card, does it shuffle the songs or just go in order of the file names?

Hi, it doesn’t have a shuffle feature on SD or USB mode. You can only use it using Bluetooth. Kindly check other details of the unit by visiting our website pyleaudio.com. Type the model number on the search box PBMSPG1BK for more details. Thank you.

• Is it supposed to be playing out of both speakers? When i turned it on it seems to only be playing out of the left speaker?

That’s because we both have been suckered! It’s just a good-looking piece of junk..yes it’s supposed to play out of bot speakers at least yours play

- **What USB charges the unit?**

Hi, the speaker is compatible with a micro USB cable. For more info, kindly visit our website pyleaudio.com. Type the model number on the search box PBMSPG1BK. Thank you.

- **Is this really 200 watts?**

Hi, yes it is our 200 watts, boombox speaker. You may check other details of the unit by visiting our website pyleaudio.com. Type the model number on the search box PBMSPG1BK for more details. Thank you.

- **How to use both speakers because it only plays from the left?**

No..cause there's only one speaker..it just looks like it's one. it's junk..you just got ha

- **Does the sound come out the sides?**

Hi, the sound comes out on both sides. You may check other details of the unit by visiting our website pyleaudio.com. Type the model number on the search box PBMSPG1BK for more details. Thank you

- **Does sound only come out of the left speaker more than the right speaker?**

That's because the tweeter is on the left side people. FYI people you need to understand sound and what a subwoofer, a mid speaker, and a tweeter. A tweeter delivers your highest frequencies, subwoofer the lowest bass frequencies. The fact that yall have made it this far in life and don't what those are is disappointing. That being said, it sounds like one side has a much lower volume so the music output is directional meaning it mainly comes out of one direction.

Read More About This Manual & Download PDF:

Documents / Resources

	<p>PYLE PBMSPG1BK Bluetooth BoomBox Speaker System [pdf] User Guide PBMSPG1BK, Bluetooth BoomBox Speaker System, BoomBox Speaker System, Bluetooth Speaker System, Bluetooth BoomBox Speaker, BoomBox Speaker, Speaker</p>
---	--

References

- [P Pyle USA Electronics | Home Audio | Car Audio & More](#)