



PYLE PBMSPG6 Portable Bluetooth Wireless BoomBox Stereo System User Manual

[Home](#) » [Pyle](#) » PYLE PBMSPG6 Portable Bluetooth Wireless BoomBox Stereo System User Manual 



PyleUSA.com

Portable Bluetooth Wireless BoomBox Stereo System, Built-in Rechargeable Battery, MP3/USB/FM Radio
Pyle BT Portable Speaker



PBMSPG6 USER GUIDE

For correctly operating, please read this manual carefully before using it. Any content revise of the manual won't declare again, and we are not responsible for consequences caused by fault or oversight of this manual



Contents

- 1 FEATURES:**
- 2 What's in the Box:**
- 3 INSTRUCTION FOR APPEARANCE AND KEY:**
- 4 Bluetooth connection:**
- 5 Playing music from a USB disk:**
- 6 How to Use FM Radio:**
- 7 AUX-IN:**
- 8 Battery Charging:**
- 9 Documents / Resources**
- 10 Related Posts**

FEATURES:


1.0 Outdoor Passive HIFI Bluetooth Speaker: Output very clear sound and dynamic sound effect; With A2DP Bluetooth, wireless stream music from any Bluetooth-enabled device such as your mobile phone, notebook, iPhone, or iPad; Secure simple pairing for user-friendly operating; 10 meters operating range; With Line-in function, suitable for PC, MID, TV, and another audio device; Built-in lithium rechargeable battery 1500mAh; With a lanyard, easy to take outside.

Digital Sound Amplifier
FM Radio with Auto-Tuning
USB Flash Drive Reader
MP3 Digital Audio File Compatibility
Aux (3.5mm) Input Jack
Side Panel Button Control Center
Full Range Stereo Sound Reproduction
Ported Enclosure Design for Impressive Bass Response

What's in the Box:

Wireless Tube Speaker
USB Charging Cable
Audio Connection Cable
Detachable Carry Strap

INSTRUCTION FOR APPEARANCE AND KEY:



1. Charging jack
2. Aux-in jack
3. USB port
4. ON/OFF button

5. Backward/Volume down
6. Mode (Switch Bluetooth, USB disk, TF, FM, and AU X-IN state)
7. Forward/Volume up
8. Play/Pause

Bluetooth connection:

1. Turn the power button to “ON”, The LED light turns blue and twinkle quickly and beep twice
2. Activate Bluetooth of mobile phone and search for device name “BT speaker” then connect it. The blue LED light will blink slowly and beep three times once connected successfully.
3. Play the music from your mobile phone and enjoy.
4. Press the Forward or Backward button on the devices or on Mobile phones to select songs you like.
5. Press the Play/pause button on the devices or on Mobile phones to play/stop the music
6. Use the Bluetooth device to adjust volume up and down. Or long-press to forwarding or Backward button to adjust volume up and down.

Playing music from a USB disk:

1. Turn the Power button to “ON”.
2. Insert USB flash disk into the slot, the music stored will be played automatically and blue LED light always keeps lighting.
3. Under playing mode, short press forward or Backward button to select songs you like, or long-press to forwarding or Backward button to adjust volume up and down.
4. PLAY/PAUSE to play or pause.

5. Please turn the Power button to “OFF” while without use.

Remark: Under Bluetooth playing mode, insert USB disk will disconnect the Bluetooth and switch the playing from USB disk. You can press the MODE button to switch to Bluetooth mode again.

How to Use FM Radio:

1. Under FM radio state, the audio cable provided is treated as antennal. Please insert the audio cable to get the best FM signal before using it.
2. Turn the power button to “ON”, press the “MODE” button to switch to FM radio state.
3. Under playing mode, short press the “Play/pause” button to auto search the FM Channel and store it automatically.
4. Press the Forward or Backward button to change the stored FM channel.

AUX-IN:

For other compatible music devices or your MP3/MP4 players, use the supplied audio line cable to connect from the device’s “Line Out” to the “Aux-In” of these devices. Then press the “MODE” button to switch to AUX-IN state. Enjoy...

When using an external device, all functions will be controlled by the external device except the “Play/pause” button.

Battery Charging:

1. Power off the unit put the provided charge cable into the charging slot of the unit, connect the other end to PC or another charger with 5V output, the red charging indicator keeps lighting.
2. Charge time should be 3-5 hours. When charging full, the indicator light will switch off.
3. In order to prolong the life of the battery, please do not charge for more than 8 hours.

Note:

1. The unit will operate without the wire connection using the lithium battery. The amount of battery life depends on how hard the unit is working. Heavy, loud, bass music will use more energy to produce than the spoken word.
2. The built-in rechargeable battery is not replaceable. Do not remove or replace it, do not throw it in the trash or in the fire.
3. When cleaning the product, use a soft dry cloth. For more severe stains, please dampen the cloth with water only. Anything else has the chance of dissolving the paint or damaging the plastic.



VISIT US ONLINE: Have a question?
Need service or repair? Want to leave a comment?
PyleUSA.com/ContactUs

Documents / Resources



[PYLE PBMSG6 Portable Bluetooth Wireless BoomBox Stereo System](#) [pdf] User Manual
PBMSG6, Portable Bluetooth Wireless BoomBox Stereo System

[Manuals+](#)