



PYLE PPHP126WMU Portable PA Speaker and Microphone System User Manual

[Home](#) » [Pyle](#) » PYLE PPHP126WMU Portable PA Speaker and Microphone System User Manual 

PYLE PPHP126WMU Portable PA Speaker and Microphone System User Manual



We recommend that you read this manual carefully so that you can fully take advantage of the advanced and convenient functions of the Portable PA Speaker and Microphone System. We also recommend that you keep this manual in a safe and handy place for future reference.

CAUTION

WARNING! DON'T OPEN THE MACHINE TO AVOID ELECTRIC SHOCK, PLEASE ASK HELP FROM PROFESSIONAL TECHNICIANS.




RISK OF ELECTRIC SHOCK DO NOT OPEN

SAFETY INSTRUCTION

1. Read this manual carefully before using. Retain for future reference.
2. All warnings on the speaker and in the operating instructions should be adhered to.
3. Do not use this apparatus near water.
4. Do not block any of the ventilation openings. Install in accordance with the manufacturers instructions. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
Do not install the speaker in an airtight location.
5. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
6. Switch OFF and unplug then use a soft cloth to clean the exterior of the unit if it becomes dirty. If necessary, use a damp cloth that has been wrung out well to wipe it.
7. Unplug this apparatus during lightning storms or when unused for long periods of time.
8. Keep foreign objects and liquid from entering the unit to avoid a short circuit, fire and electrical accidents.
9. Place the speaker in a dry location.
10. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture , does not operate normally, or has been dropped.

FRONT CONTROL PANEL FUNCTION & OPERATION





MIC. Vol: Increase/decrease the microphone volume.

Volume: Increase/decrease the main volume.



0 – 1 – 9 + Numeric keys: Press to select the song.

To select previous song—

-  **Mp3 Mode:** Short press for previous song and press and hold for fast forward.
- **FM mode:** Short press for previous station and press one for searching the station.
-  **AUX mode:** Do not press, it is useless.

To select next song—

- **Mp3 Mode:** Short press for next song, press and hold for fast forward.

- **FM mode:** Short press to choose next station, press one to searching the station.
- **AUX mode:** Do not press, it is useless.
-  **Play & Pause**
- **Mp3 mode:** Play and pause, cycle playing.
- **FM mode:** Play and pause, and press and hold for searching radio stations.
- **AUX mode:** Short press to play and pause.
- **M: Input mode change—** Short press to change between Blue-conn/FM/USB/
- **Micro SD/MMC/AUX mode.**
-  **Under music mode,** short press to single repeat, press and hold for cycle repeat.
- **PS:** Insert Micro SD/MMC card
- **Micro SD/MMC/USB 8G** maximum supported memory.

REMOTE CONTROL OPERATION INSTRUCTION



Standby: Power ON/OFF the machine.

MODE

: Audio input select key, input choose between **AUX/Blue-conn/FM/USB/Micro SD/MMC.**



Mute: Press to mute the sound. Press it again to unmute the sound.



Play & Pause: Same function as front control panel.

Previous: Same function as front control panel.

Next: Same function as front control panel.

EQ: Choose sound effect between normal, jazz, rock, pop, classic, country six different sound effects.



: USB/Micro SD/MMC volume adjust.

USB/Micro SD: Press it to select USB or Micro SD input.



: Short press for single repeat play, press and hold for cycle repeat play.

0, 1, ...9, 100 + NUMBER keys: Press these number keys to select Mp3 song.



ADDITIONAL FUNCTION INSTRUCTION

ON/OFF: Power ON/OFF


DC13.5V/1.5A IN: 13.5V/1.5A charger jack.

LED: LED lights under working status.

MIC IN: Microphone connect port.

AUX IN: Auxiliary input.

ECHO: Echo adjust for microphone.





charge the speaker within the voltage of AC100V-240V 50/60Hz only.



Don't open or repair the machine. Refer all servicing to qualified service personnel.




DO NOT install near any heat sources, Place the equipment in a well ventilated area.



Don't throw metal materials into the machine.



DO NOT expose this apparatus to dripping or splashing and ensure that no objects filled with liquids, such as vases, are placed on the apparatus.



UNPLUG this apparatus during lightning storms or when unused for long periods of time.



RISK OF ELECTRIC SHOCK DO NOT OPEN

Do not open! Risk of Electrical Shock. Voltages in this equipment are hazardous to life. No user-serviceable parts inside. Refer all servicing to qualified service personnel.



System Features

- High-Powered PA Sound System
- Rugged & Compact Speaker Designed for Portability
- Perfect for Karaoke, Stage Performances, Crowd Control
- Wireless BT Music Streaming Ability
- Multi-Color Dancing DJ Party Lights
- Built-in Rechargeable Battery
- Sound System: 12" Full Range Stereo Speaker + 1.5" Tweeter
- Microphone Priority 'Talk-Over' Switch
- USB Flash & Micro SD Memory Card Readers
- FM Radio with LCD Display
- Recording Function
- 1/4" Microphone Input
- Aux (3.5mm) Jack
- Connect & Stream Audio from External Devices
- External 12V Power DC Input Connectors
- Mic Volume, Treble, Bass, Echo Controls
- Telescoping Handle & Rolling Caster Wheels

Bluetooth Connectivity

- Built-in Wireless BT Music Streaming
- Works with All of Your Favorite Devices (iPhone, Android, Smartphone, iPad, Tablet, Computer, etc.)

- Wireless BT Version: 3.0
- Wireless BT Network Name: 'PyleUSA'
- Wireless Range: 70'+ ft.

What's in the Box

- PA Speaker System
- Wired Microphone
- Beltpack Transmitter
- Headset Microphone
- Remote Control
- Wall Power Adapter

Technical Specs

- **MAX Power Output:** 700 Watt
- **Construction Material:** Molded ABS Cabinet
- **DJ Party Lights** ON/OFF Switch
- **Impedance:** 4 Ohm
- **Frequency Response:** 55-20kHz
- **S/N Ratio:** 60Db +/-3dB
- **SPL:** 94dB (1W/M)
- **T.H.D.:** <1%
- **Battery:** Lithium 11.1V, 1800mAh
- **Digital File type Compatibility:** MP3, WMA,
- **Maximum USB/Micro SD Support Size:** 32GB
- **Power:** 110/220V (13.5V DC Adapter)



VISIT US ONLINE :

Have a question?

Need service or repair?

Want to leave a comment?

PyleUSA.com/ContactUs

Questions? Issues?

We are here to help!

Phone: (1) 718-535-1800

Email: support@pyleusa.com



Documents / Resources



[PYLE PPHP126WMU Portable PA Speaker and Microphone System](#) [pdf] User Manual
PPHP126WMU, Portable PA Speaker and Microphone System

[Manuals+](#).