

PYLE PPHP854B 8" Wireless BT Portable PA Speaker User **Manual**

Home » Pyle » PYLE PPHP854B 8" Wireless BT Portable PA Speaker User Manual








PPHP854B 8" Wireless BT Portable PA Speaker


MP3/USB/ /FM Radio (300 Watt MAX) USER MANUAL

WARNING



The illegal operation may cause personal injury, which could be fatal and may cause damage to property.


FRONT PANEL FUNCTIONS



- 1. Master volume control
- 2. Charge LED indicator
- 3. DC 5V input jack
- 4. Short press to choose input signal, press and hold t o turn ON/OFF light
- 5. Next/select saved radio station.
- 6. Play/Pause/TWS function/In FM mode, press and h old to search radio station automatically and save.
- 7. Previous/select saved radio station
- 8. AUX input jack
- 9. USB input jack
- 10. Microphone input jack
- 11. Display screen

REMOTE CONTROL FUNCTIONS

- 1. Power: Used to turn on and off the MP3 player power
- 2. MODE: Used to switch the AUX/ USB/Wireless BT/Radio
- 3. Mute button
- 4. Play/Pause/Press and hold for TWS/ In FM mode, press and hold to search radio station automatically and save
- 5. Next song/In FM mode, short press to select saved radio station
- 6. Previous song /In FM mode, short press to select saved radio station
- 7. EQ solution
- 8. Increase volume
- 9. Choose song number directly/ In FM mode, choose FM Frequency directly
- 10. Choose USB or SD signal directly (Only suitable for models with USB & SD both)
- 11. Decrease volume
- 12. Repeat the song



TWS FUNCTION

To increase the sound effect, our unit provides TWS function as follows:

Step-1: Turn ON BT mode on your device and connect the machine.

Step-2: Press and hold each control board "**TWS**" button more than 3's, and you will see "**ON**" on display, unit will start to connect to the other unit automatically, now you can enjoy stereo sound, and adjusting one unit volume will affect the other unit.

Remark:

1. After connection, press and hold again one of the control board "TWS" buttons more than 3's, you will see "OFF" on display, unit's TWS disconnection.

TROUBLESHOOTING

Fault	Possible Cause	Solution
No sound	No input sound source. Volume is too low.	Use a better music signal. Adjust the volume.
Distortion of sound	Volume too high. Speaker may be damaged	 Turn down the volume. If the speaker is damaged, repair or replace it.
Karaoke does not wor k	 Microphone plug is not fully inserted. Microphone switch is not on. Microphone volume knob is at the lowest p osition. 	 Plug the microphone properly into the socket. Turn on the microphone switch. Adjust microphone volume properly.
MP3 does not play	 The audio format in the U disc is incorrect. Improper operation has caused a processin g disorder. USB disc is disconnected. 	 Convert audio format into Mp3 format. Reboot the machine. Insert USB disc properly.

Features:

- True Wireless Stereo System
- Portable Speaker System
- High-Powered PA Loudspeaker Style
- Wireless BT Music Streaming Ability
- Multi-Color Flashing LED Party Lights
- Built-in Rechargeable Battery
- FM Radio with Digital LED Display
- Connect & Stream Audio from External Devices

- Aux (3.5mm) Input Connector Jack
- USB Flash Memory Reader
- 6.5mm Microphone input
- Battery Level LED Indicator Lights
- Rugged & Durable Molded Cabinet Design
- Convenient Extendable Carry Handle
- For Indoor / Outdoor Use

Wireless BT Streaming:

- Built-in BT for Wireless Music Streaming
- Simple & Hassle-Free Pairing
- Works with All of Today's Latest Devices
- Smartphones, Tablets, Laptops, Computers, etc.
- Wireless BT Version: 4.2
- Wireless BT Network Name: 'PYLEUSA'
- Wireless Range: Up to 32' ft.

What's in the Box:

PA Speaker System	Power Adapter
Remote Control	Straps

Technical Specs:

• Material: Polypropylene (PP)

• Max Power Output: 300 Watt Max

• Sound System: 8" -inch Subwoofer

• Impedance: 3.0 Ohm

• Frequency Response: 50Hz-12KHz

• USB Interface Type: 2.0

• Digital Audio File Support: MP3

- Maximum USB Flash Support: 32GB
- Remote Control Battery Operated, 1 Piece Button
 Cell Battery CR-2025 (Included)
- Battery Life: Up to 2 Hours (Charge Time: Approx. 4 Hours)
- Rechargeable Battery: 3.7V, 1800mAh 6.66 Wh
- Power Supply: 120/240V, Switchable (5V/2A Power Adapter)
- Dimensions (L x W x H): 9.9" x 6.5" x 11.8" -inches

warning: This product can expose you to a chemical or group of chemicals, which may include "Lead and lead compounds" which are known in the state of California to cause cancer, birth defects, or other reproductive harm. For more info, go to https://www.p65warnings.ca.gov/.





VISIT US ONLINE:

Have a question? Need service or repair? Want to leave a comment?

PyleUSA.com/ContactUs

Questions? Issues? We are here to help!

Phone: (1) 718-535-1800 Email: <u>support@pyleusa.com</u>

Documents / Resources



PYLE PPHP854B 8" Wireless BT Portable PA Speaker [pdf] User Manual PPHP854B, 8 Wireless BT Portable PA Speaker

Manuals+.