

PYLE Wireless and Portable PA Speaker System Kit User Manual

Home » Pyle » PYLE Wireless and Portable PA Speaker System Kit User Manual



PYLE Wireless and Portable PA Speaker System Kit User Manual

We recommend that you read this manual carefully so that you can fully take advantage of the advanced and convenient functions of the Portable PA Speaker and Microphone System. We also recommend that you keep this manual in a safe and handy place for future reference.

PWMA1090UI

WARNING! DON'T OPEN THE MACHINE TO AVOID ELECTRIC SHOCK, PLEASE ASK HELP FROM PROFESSIONAL TECHNICIANS.

Caution! Risk of Electric Shock! Do Not Open!


Contents

- 1 SAFETY INSTRUCTION
- 2 SYSTEM FUNCTION FIGURE
- **3 INSTRUCTIONS**
 - 3.1 Confirm the power
 - 3.2 Operation Instructions
 - 3.3 Wired Microphone
- 4 What's in the Box:
- **5 System Features:**
- **6 Technical Specs:**
- 7 Support/Contact
- 8 Documents / Resources
 - 8.1 References
- 9 Related Posts

SAFETY INSTRUCTION


- 1. Read this manual carefully before using. Retain for future reference.
- 2. All warnings on the speaker and in the operating instructions should be adhered to.
- 3. Do not use this apparatus near water.
- 4. Do not block any of the ventilation openings. Install in accordance with the manufacturers instructions. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
 - Do not install the speaker in an airtight location.
- 5. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- 6. Switch OFF and unplug then use a soft cloth to clean the exterior of the unit if it becomes dirty. If necessary, use a damp cloth that has been wrung out well to wipe it.
- 7. Unplug this apparatus during lightning storms or when unused for long periods of time.
- 8. Keep foreign objects and liquid from entering the unit to avoid a short circuit, fire and electrical accidents.
- 9. Place the speaker in a dry location.
- 10. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

SYSTEM FUNCTION FIGURE



- 1. Wireless Mic/MIC 1 Volume Control
- 2. MIC 2 Volume Control
- 3. Guitar Volume Control
- 4. Audio Volume Control
- 5. Ipod Dock
- 6. Ipod/MP3 Volume Control
- 7. Echo Control
- 8. Treble Control
- 9. Metal Corner
- 10. Bass Control
- 11. SD/MMC Card Jack
- 12. USB Jack
- 13. Screen
- 14. Play/Pause Control
- 15. Next Control
- 16. Prev Control
- 17. Mode Control
- 18. Remote Signal Control
- 19. Tweeter
- 20. Vent Hole
- 21. Unit Fixed Stand

- 22. Vent Hole
- 23. Woofer Speaker
- 24. Guitar Input Jack
- 25. Audio Output Jack
- 26. Ipod/MP3 Input Jack
- 27. Audio Input Jack
- 28. MIC 2 Input Jack
- 29. Power Switch
- 30. MIC 1 Input Jack
- 31. Power Indicator
- 32. Low Voltage Indicator
- 33. Charge Indicator
- 34. Wireless Mic RF Indicator
- 35. Trailer Handle
- 36. Heating Pane
- 37. Handle
- 38. Voltage Selector Switch
- 39. Radio Antenna
- 40. Audio Output
- 41. Power Socket
- 42. AC Fuse/Battery Fuse
- 43. Warning label
- 44. DC12V Input Jack
- 45. Trailer Fixed Stand
- 46. Battery Cover
- 47. 7AH/12V Rechargeable Battery
- 48. Trailer Truckle
- 49. Lavalier Mic
- 50. Headset Mic
- 51. Handheld Mic



INSTRUCTIONS

Confirm the power

AC Power: Before operation, please confirm the voltage is same as the specified marked on the label. If not, the unit will be damaged. Built-in Rechargeable Battery: Plug-in the AC power when the rechargeable battery voltage is enough but use the battery directly. When the Low Voltage indicator turns yellow, it indicates the low battery, please charge it in time. When the Low Voltage indicator turns OFF, it indicates the voltage is standard now. If the unit will not be used for a long time, please charge the rechargeable battery every 2 months, 8-10 hours for each time.

Operation Instructions

- Plug the power cable into the socket and connect it with this amplifier system.
- Switch ON the amplifier. the Power Indicator comes red.
- During charging, RECHARGE indicator turns red, when the indicator is flashing, that means battery is almost full and turns OFF when fully charged.
- During charging, you can play music at the same time, the RECHARGE indicator will flash with the current comsuption indicating the speed of charge. Charge time is in direct proportion to the volume of music. When the battery is full, RECHARGE indicator will stop flashing and turns off.
- Put two AA 1.5V battery into handheld microphone (bodypack transmitter), push the Power Switch to the middle, the Power Indicator will flash once, RF Indicator turns green.
- Push the handheld microphone Power Switch (bodypack transmitter) to ON position, your sound can be heard from amplifier when speaking.
 - Adjust the Volume Control/Echo Control/Treble Control/Bass Control to proper position to avoid feedback.
- If the microphone Power Indicator (bodypack transmitter) turns on at all times, it indicates the low battery, please replace the battery.
- Connect relative guitar cable with Guitar Input Jack on this system to play music.
- **IPOD Dock:** equipped with an iPod dock connector that charges your iPod or iPhone and lets you play your favorite music over the powerful 800W speaker.
 - Press "Play", "Pause", "Pre' and "Next" keys to control and play music. The unit will charge ipod automatically once connected to the dock until battery is full.
 - No need to press "Charge" key to get charged. During charging, you can play ipod at the same time

Wired Microphone

- Two way wired microphone input jacks are supplied for two people to use simultaneously.
- Plug Wired microphones into the jacks separately. Adjust Echo Control to get better sound.
- · Adjust the volume of each microphone to make sure the sound is satisfactory.

When you turn on the unit, be sure ECHO control is set to low or there will cause sound distortion.

What's in the Box:

- PA Loudspeaker
- · Wireless Handheld Microphone

- Beltpack Transmitter
- Lavalier Headset Microphone
- Audio Connection Cables
- Power Cable
- · Remote Control

System Features:

- High-Powered 10" 3-Way PA Loudspeaker System
- Full Range Stereo Sound: Built-in Subwoofer, Mid-Range, Tweeter
- 30-Pin iPod/iPhone Dock: Charge Your Device and Play Music
- USB Flash & SD Memory Card Readers
- FM Radio with LCD Digital Display
- Retractable AUX (3.5mm) Input Cable
- Connect & Stream Audio from External Devices
- Built-in Rechargeable Battery for Hours of Wireless Use
- · Front-Facing Control Center
- Easy-to-Use Rotary Knobs and Push Button Controls
- Connect up to (2) Microphones and (1) Guitar
- Inputs: (1/4") Mic1, Mic2, Guitar, Audio, iPod/MP3, Balanced Connector Jacks
- Outputs: (RCA) Audio Out, (1/4") Audio Out
- Independent Volume Controls for Mic1, Mic2, Guitar, iPod/MP3, Input
- Portable Enclosure with Telescoping Handle and Caster Wheels
- · Echo, Bass and Treble Adjustments
- RF, Charge, Low Battery, and Power LED Indicators
- 35mm Speaker Stand Mount Insert

Technical Specs:

- Power Output: 800 Watt MAX 400 Watt RMS
- All Inputs/Outputs 1/4" TS/unbalanced
- **SPL**: 94dB (1W/M)
- T.H.D.: <1%
- Input Wired Mic: -58dB V600
- Dimensions (L x W x H): 12.4" x 13.0" x 26.0"
- 110/220V Switchable

Support/Contact



Have a Question?
Need Service or repair?
Want to leave a comment?
PyleUSA.com/ContactUs

Questions? Issues?

We are here to help! **Phone:** (1) 718-535-1800

Email: support@pyleusa.com

Documents / Resources



PYLE Wireless and Portable PA Speaker System Kit [pdf] User Manual PWMA1090UI, Wireless and Portable PA Speaker System Kit

References

Pyle USA Electronics | Home Audio | Car Audio & More

Manuals+,