

PYRAMEX SL T2 Type II Half Visor Instruction Manual

Contents

- [1 PYRAMEX SL T2 Type II Half Visor Instruction Manual](#)
- [2 SL T2™ VISOR AND CLIPS](#)
- [3 Documents / Resources](#)
 - [3.1 References](#)

PYRAMEX SL T2 Type II Half Visor Instruction Manual

SL T2™ VISOR AND CLIPS

To Attach Clips to Helmet:

1. Check for L and R indicators on the backside of each clip.
2. Place the left and right clips in the corresponding front accessory slots of the helmet.

To Attach Visor to Clips:

1. Position the visor over the holes on the clips on the front accessory slots.
2. Press in to ensure a secure fit.

To Remove Visor from Clips:

1. Press the button labeled "PUSH" on the top of the clip to release the visor.
2. Gently pull the visor away from the clips.

To Remove Clips from Helmet:

1. Simply pull up on clips to detach them from helmet.

Documents / Resources



[PYRAMEX SL T2 Type II Half Visor](#) [pdf] Instruction Manual
HPT2HV_0T, HPT2V10T, HPT2V20T, HPT2CLIPS, HPT2PV, HPT2FV10, HPT2FVM60, SL T2
Type II Half Visor, SL T2, Visor, Half Visor, SL T2 Half Visor, Type II Half Visor

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.