

QBWIEDOMLIT QB-807 Bubble Fog Machine



QBWIEDOMLIT QB-807 Bubble Fog Machine User Manual

[Home](#) » [QBWIEDOMLIT](#) » QBWIEDOMLIT QB-807 Bubble Fog Machine User Manual 

Contents

- 1 QBWIEDOMLIT QB-807 Bubble Fog Machine
- 2 Product Information
- 3 Product Usage Instructions
- 4 INTRODUCTION
- 5 ACCESSORIES LIST
- 6 SPECIFICATIONS
- 7 PARTS NAME
- 8 HOW TO USE
- 9 MAINTENANCE & CLEANING
- 10 WARRANTY
- 11 Documents / Resources
 - 11.1 References

QBWIEDOMLIT

QBWIEDOMLIT QB-807 Bubble Fog Machine



Product Information

Specifications:

- **Product:** Fog Bubble Machine
- **Model No.:** QB-807

Product Usage Instructions

Preparation:

Before using the machine, prepare specialized Fog Fluid and Bubble Fluid separately.

Usage Steps:

1. Place the machine on a clean, flat, and solid surface near a grounded wall outlet.
2. Unscrew the lid of the fog liquid tank at the back of the machine and pour in the fog fluid. Tighten the lid.
3. Pour bubble fluid into the bubble liquid tank at the front of the machine ensuring the tube can suck up the liquid.
4. Plug in the A/C power cord to the wall outlet.
5. Turn on the Power Switch at the back, indicated by a red light.
6. Wait for 2 to 4 minutes for warm-up. The blue light will indicate readiness.
7. Turn on the Function Switch on top to start operation.
8. Ensure the switch is off before refilling fluids.
9. Unplug the power cord when not in use.

Maintenance & Cleaning:

1. Unplug the power cord before maintenance.
2. Empty residual liquids from drainage outlets.
3. Pour 300ml distilled water into each tank and run for 5-10 minutes.

4. Clean the surface with a soft, dry cloth only.

FAQ:

1. Q: What should I do if there is liquid residue buildup?


A: Clean the residue from the front of the machine to prevent slipping hazards. Use caution when cleaning and ensure the machine is unplugged.

2. Q: What is the warranty policy?

A: The product comes with a 30-day refund guarantee, a 90-day replacement/refund for quality-related issues, and a 24-month warranty for quality-related issues under proper use. Contact customer service for more information.

3. Q: How should I dispose of the product?

A: Do not dispose of the product in normal waste. Follow European Directive 2012/19/EU for disposal via an approved company or waste facility. Contact your waste disposal center for further information.



- FOG BUBBLE MACHINE
- **Model No.:** QB-807
- USER INSTRUCTIONS

INTRODUCTION

Thank you for purchasing Wisdom lit Fog Bubble Machine. this user instructions contains the important information about safety, usage and disposal. Use this product as described and keep the instructions for future reference. If you sell this unit or pass it on, also give this instructions to the new owner.



ACCESSORIES LIST

- 1 x Fog Bubble Machine
- 2 x Handle Screws
- 1 x User Manual
- 1 x Handle
- 1 x Replaceable Fuse (5A/125V)


SPECIFICATIONS

- **Power Supply:** AC120V. 60Hz
- **Power Consumption:** 450W
- **Fuse:** SA/ 125V
- **Warm-up Time:** 2~4 Minutes
- **Material:** Metal Housing
- **Dimension:** 13.54 x 7.36 x 9.17 inches (344 x 187 x 233mm)
- **Control Mode:** Switch ON/OFF
- **Tank Capacity for Bubble Liquid:** 15.87oz. (450ml)
- **Tank Capacity for Fog Liquid:** 12.35oz. (350ml)

PARTS NAME



1. Handle
2. Working LED Indicator
3. Bubble Liquid Level Mark
4. Scrapper
5. Function Switch
6. Fan Cover
7. Nozzle
8. Bubble Liquid Tank



- 9. Bubble Liquid Drainage Outlet
- 10. Fog Liquid Tank
- 11. Fog Liquid Level Mark
- 12. Fuse
- 13. Fog Liquid Drainage Outlet
- 14. Power Switch

HOW TO USE

ATTENTION: Before using this machine, you should prepare the specialized Fog Fluid and Bubble Fluid separately.

Once prepared, operation according to the following steps.

1. Place the unit onto a clean, flat and solid surface, close to a standard A/C grounded wall outlet.
2. Unscrew the lid of fog liquid tank at the back of machine, and pour fog fluid into the tank, then tighten the lid of tank.
3. Pour bubble fluid into the bubble liquid tank at the front of machine, check and ensure the tube can suck up bubble liquid in the tank.

WARNING: Fog Fluid must be pour into FOG LIQUID TANK, and Bubble Fluid must be pour into BUBBLE LIQUID TANK. DON'T OVERFILL AND MAKE IT THE OTHER WAY AROUND!

4. Plug the A/C power cord into the A/C grounded wall outlet.
5. Turn on Power Switch at the back of machine, a Red light will light up indicating the unit is ON.
6. Warm up time is approximately 2 to 4 minutes. When fully heated, the Blue light at the front of unit will light up indicating that the machine is ready.
7. Turn on Function Switch on top of unit, the machine will be in working.
8. Keep the switch OFF before refilling your fog / bubble fluid into their tank of unit.
9. When not in use, unplug the A/C power cord from the A/C grounded wall outlet.

ATTENTION: When the Red light at the front of unit light up, pour more fog fluid into fog liquid tank.



CAUTION:

There's liquid residue to build up in the front ground of the of the machine. This can cause a slick area and create a slipping hazard.

MAINTENANCE & CLEANING

1. Unplug the A/C power cord before maintenance and cleaning.
2. Empty the residual fog liquid and bubble liquid from their liquid drainage outlet.
3. Pour 300ml distilled water into each liquid tank, and let this machine work for 5 to 10 minutes.
4. Surface clean only with a soft, dry cloth.

CAUTIONS & WARNINGS

- This product is recommended for indoor use only. To reduce the risk of fire or shock hazard, do not expose this product to rain, moisture or dust.
- Hot surface. Avoid contact, always use the handle to carry the fog bubble machine.
- Replace fuse only with 5.0 Amps, 125 Volts fuse.
- For adult use only. Keep out of reach of children and pets. When children or pets are present, close adult supervision is necessary.
- Always operate the unit in an open, well-ventilated area.
- Do not leave unattended while in use. Always unplug the unit from the electrical outlet when unattended.
- Use with a 3 prong, grounded electrical outlet only.
- Do not operate within 3 feet of electrical devices, such as refrigerators, televisions, microwaves or heaters.

WARRANTY

- **30-Day Refund Guarantee**
 - Wisdomlit Fog Bubble Machine are eligible for a refund for any reason within 30 days of purchase. Please contact customer service for refund information and they will reply within 48 hours.
- **90-Day Replacement / Refund for Quality-Related Issues**
 - All Wisdomlit Fog Bubble Machine can be replaced or refunded within 90 days of purchase for quality-related issues or breakdowns not caused by improper use or improper maintenance.
- **24-Month Warranty for Quality-Related Issues**
 - Wisdomlit Fog Bubble Machine that break within 24 months due to normal, proper use can be replaced at no cost.
- **NOTE**
 - Product damage caused by improper use or improper maintenance is not covered by warranty.
- **Contact Customer Service At:**
 - Email: wisdomlit_service@outlook.com

Disposal



Disposal of this Product


- Under no circumstances should you dispose of this product in normal domestic waste.
- This product is subject to the provisions of European Directive 2012/19/EU.
- Dispose of this product via an approved disposal company or your municipal waste facility.
- Please observe currently applicable regulations.



- Please contact your waste disposal center if you need any further information.
- This product's packaging is made from environmentally friendly material and can be disposed of at your local recycling plant.



Documents / Resources

	<p>QBWIEDOMLIT QB-807 Bubble Fog Machine [pdf] User Manual QB-807 Bubble Fog Machine, QB-807, Bubble Fog Machine, Fog Machine</p>
-------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------------

References

- [User Manual](#)

Manuals+ Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.