



QOMO QPC20 F1 Flip Portable Document Camera User Manual

[Home](#) » [QOMO](#) » QOMO QPC20 F1 Flip Portable Document Camera User Manual 



QPC20 F1 User Manual
V2.0 02/02/2022
1 V2.0 02/02/2022

The document camera is a quick and easy way to display your document or object in real-time, or capture them as high-quality digital files.

Contents

- [1 Features at a Glance](#)
- [2 Product Overview](#)
- [3 Connecting and Downloading Software to Computer](#)
- [4 Troubleshooting](#)
- [5 Specification Sensor](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)
- [7 Related Posts](#)

Features at a Glance

- **Auto-focus Mode:** Stream live images directly to your computer in full clarity.
- 8.0 Megapixel camera for exceptionally detailed HD images up to 3264x 2448 pixels
- USB portable design makes it easy to move around the device and capture images effortlessly
- Built-in LED light to view images in any lighting Capture docs, textbooks, devices, 3D objects, and more

without taking up desk space.

- Available Software for Mac, Windows, and Chrome OS.

Product Overview



Connecting and Downloading Software to Computer

Connect document camera to computer via USB cable. Once connected, the LED indicator will illuminate. Install camera software from www.qomo.com/qcamera. The software supports Windows, Mac OS and Chrome OS.

Camera may be used with other third party software that support USB cameras. Select the camera on the third party software to view the image.

Troubleshooting

4.1 No image

1. **Cause:** Poor connection
2. **Solution:** Check the USB cable is connected and the LED light is on

4.2 Poor focus

Cause:

1. Not enough light or too much light
2. Object beyond focus
3. Dirt on the camera lens

Solution:

1. Turn on/off Lamp Light and

2. Move camera slightly to refocus.
3. Use a cloth to clean the camera lens

4.3 No video after the application starts or after the device is selected

Cause: Document Camera is being used in another program

Solution: Re-connect the USB and choose the device & close another program


4.4 Video is not smooth Cause: Computer configuration might be low Solution: Change the Camera to lower definition.

Specification Sensor

Sensor	8 Megapixel Auto-focus CMOS Digital Image Sensor
Frame Rate	up to 30fps
Focus Mode	Auto Focus
image Resolution	3264x2448@10fps 2592x1944@15fps, 2048x1536@20fps, 1920x1080@30fps, 1600x1200@30fps, 1280x720@30fps, 640x480@30fps
Computer	USB Plug-n-Play
Power	USB 5V, Powered by PC
Display Area	A4(210mm x297mm), or other smaller sizes
Lighting	LED light
Zoom	YES
Image Rotation	0°, 90°, 180°, 270°
Spilled	YES
Title	YES
Freeze	YES
Compatibility	Windows, Mac, Chrome OS (support Google Play Store)
Certifications	CE, FCC, RoHS
Dimensions	310mm '100mm '128mm
Dimension	310mm '280mm '128mm
Weight	1.5 lbs
Accessories	USB Cable, CD

6 V2.0 02/02/2022

Documents / Resources

 The thumbnail shows the cover of the 'QOMO QPC20 F1 User Manual'. It features the QOMO logo at the top, followed by the title 'QPC20 F1 User Manual'. Below the title is a green horizontal bar with the text 'QPC20 F1' in white. The rest of the cover is white with some faint, illegible text at the bottom.	<p>QOMO QPC20 F1 Flip Portable Document Camera [pdf] User Manual</p> <p>QPC20 F1, Flip Portable Document Camera, QPC20 F1 Flip Portable Document Camera, Portable Document Camera, Document Camera, Camera</p>
---	--

References

-  [QCamera | Document Camera Software | QOMO](#)