



**TB205**  
**Reusable Dual**  
**Snow Chains**



## Quality Chain TB205 Reusable Dual Snow Chains Installation Guide

[Home](#) » [Quality Chain](#) » Quality Chain TB205 Reusable Dual Snow Chains Installation Guide 

### Contents

- [1 Quality Chain TB205 Reusable Dual Snow Chains](#)
- [2 INSTALLATION INSTRUCTION](#)
- [3 Disassembly](#)
- [4 Documents / Resources](#)
  - [4.1 References](#)



### Quality Chain TB205 Reusable Dual Snow Chains





## INSTALLATION INSTRUCTION


### REUSABLE DUAL SNOW CHAINS INSTALLATION INSTRUCTIONS

#### Installation Steps

1. Pass the fastener through the first recess of the chain.
2. Continue to the second recess.



3. Rotate the shaft using the special wrench until it is tight.
4. Installation complete.



- Please read the instructions carefully and keep them for future reference

## Disassembly

- If you want to remove the chains, press the metal clasp and pull out the fastener.



## Documents / Resources



[Quality Chain TB205 Reusable Dual Snow Chains](#) [pdf] Installation Guide  
1a01, 80de, 1243999, TB205 Reusable Dual Snow Chains, TB205, Reusable Dual Snow Chain  
s, Dual Snow Chains, Snow Chains

## References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.