



Qulose Pro X Surface Keyboard User Manual

[Home](#) » [Qulose](#) » Qulose Pro X Surface Keyboard User Manual 

Qulose Pro X Surface Keyboard User Manual

Contents

- [1 Connection Instructions](#)
- [2 Backlight Control](#)
- [3 Charging](#)
- [4 Touch Function](#)
- [Gestures](#)
- [5 Backlight Specifications](#)
- [6 Safety Caution](#)
- [7 FAQ](#)
- [8 Packing List](#)
- [9 Documents / Resources](#)
 - [9.1 References](#)
- [10 Related Posts](#)

Connection Instructions

How to connect the keyboard?

Backlight Control

Press “Fn” + to adjust brightness mode

Press “Fn” + to switch between seven colors.

1. If no buttons are pressed within 1 minute the backlight will turn off automatically.

2. The backlight function will be turned off automatically when the battery is low.

1. Magnetic stripe
2. USB charging
3. Power switch
4. CAPS light
5. PAIR light
6. CHRG light
7. Touchpad

- Esc
- Mute
- Screenshot
- Page Down
- Decrease Screen Brightness
- Volume Down
- Start of the line
- Delete
- Increase Screen brightness
- Volume up
- End of the line
- Play / Pause
- Adjust Backlight Brightness
- Page up

Table 1

Turn the touchpad function on/off

Charging

1. The keyboard charging port is TYPE-C charging port, the input of the voltage can not exceed DC-5V the keyboard will be broken if the voltage exceed the limit.
2. Connect the TYPE-C plug of the charging cable to the keyboard charging socket the other side is connected to the charger of the tablet PC or the charging interface of the tablet PC charges the keyboard.
3. Please charge it for at least 3 hours before using for the first time and then charging at least 2 hours when it is low battery in the future.
4. The green indicator light flashes: low battery, please charge it on time.
5. When charging, please check whether the charging port is powered normally.

Note: Please do not charge the keyboard for a long time. Keeping it plugged in for a long time will deplete the keyboard's battery life

Touch Function Gestures

Table 2

Backlight Specifications

Table 3

Safety Caution

1. Keep the item away from sharp objects.
2. Do not place heavy object on the keyboard.
3. Away from microwave items.
4. Do not force or distorted the keyboard.
5. Keep away from oil,chemical or other organic liquid,items.

FAQ

Table 4


Packing List

1. Touchpad Keyboard for Surface Pro 8/Pro X
2. Type-C Charging Cable (No Charger)
3. Keyboard Manual

Contact Us

If you have any use problems with our keyboard,please do not hesitate to contact us via + support@qulose.com!
Please rest assured that we will definitely help you solve them!
The device is provide with one-year limited hardware warranty from the purchase day.

Documents / Resources

	Qulose Pro X Surface Keyboard [pdf] User Manual Pro X Surface Keyboard, Pro X, Surface Keyboard, Keyboard
---	--

References

- [User Manual](#)