



**1654677 Giro  
Matte White ABS  
Square Inwall  
Cistern Buttons**



## R and T 1654677 Giro Matte White ABS Square Inwall Cistern Buttons Owner's Manual

[Home](#) » [R and T](#) » R and T 1654677 Giro Matte White ABS Square Inwall Cistern Buttons Owner's Manual 

### Contents

- [1 R and T 1654677 Giro Matte White ABS Square Inwall Cistern Buttons](#)
- [2 Specifications](#)
- [3 Dimension](#)
- [4 Installation](#)
- [5 Operation](#)
- [6 INWAL ABS BUTTONS](#)
- [7 Maintenance](#)
- [8 Frequently Asked Questions](#)
- [9 Documents / Resources](#)
  - [9.1 References](#)



**R and T 1654677 Giro Matte White ABS Square Inwall Cistern Buttons**



## **Specifications**

- Product Name: INWALL ABS BUTTONS
- Issue Date: 11.12.23
- WAZE BUTTON Models: 1654674, 1654675, 1654676
- GIRO BUTTON Models: 1654677, 1654678, 1654679


## **INWALL PACKAGE INCLUDES**

- TOILET PAN
- R&T CISTERN
- ABS BUTTON

## **Disclaimer**

Products in this specification manual must by regulation be installed by licensed and registered trade people. The manufacturer/distributor reserves the right to vary specifications or delete models from their range without prior notification. Dimensions and set-outs listed are correct at the time of publication however the manufacturer/distributor takes no responsibility for printing errors. Have actual item onsite before commencing any works Allow +/- variations to the measurements listed here.

## **Dimension**



**Warning:** For actual inlet height have pan onsite

- Wall Faced Pan
- Short Projection 540mm
- Rimless Flush
- Nano Antibacterial Coating in Pan
- Soft Close Sandwich Seat
- Universal trap – s or P
- S Trap Setout 90mm – 110mm
- P Trap Setout 180mm
- 4 star WELS – 4.5/3L

## Installation

1. Ensure that you have the necessary tools and equipment for installation.
2. Follow the installation guidelines provided in the user manual carefully.
3. If you are not a licensed trade person, seek professional installation services.
4. Verify the dimensions and set-outs before beginning the installation process.

## Operation


1. To use the WAZE BUTTON, press the corresponding button model (1654674, 1654675, or 1654676) as needed.
2. To use the GIRO BUTTON, press the appropriate button model (1654677, 1654678, or 1654679) for its intended function.
3. Ensure proper functioning of the buttons after installation for seamless operation.

## INWAL ABS BUTTONS


WAZE  
ROUND BUTTON  
1654674  
ABS  
MATTE BLACK



WAZE  
ROUND BUTTON  
1654675  
ABS  
CHROME




WAZE  
ROUND BUTTON  
1654676  
ABS  
MATTE WHITE





GIRO  
SQUARE BUTTON  
1654677  
MATTE BLACK  
ABS



GIRO  
SQUARE BUTTON  
1654678  
CHROME  
ABS




GIRO  
SQUARE BUTTON  
1654679  
MATTE WHITE  
ABS



- ABS ECONOMICAL AND FUNCTIONAL
- DUAL FLUSH
- SLIMLINE DESIGN
- BUTTON PLATE IS REMOVAL

## INWALL R&T CISTERN



- INWALL CISTERN FOR FLOOR MOUNT WALL
- FACED PANS 1654686
- WELS 4 STAR, 4.5L/3L

## Maintenance

Regularly clean the buttons with a soft, damp cloth to prevent dust buildup and maintain their appearance and functionality.

## Frequently Asked Questions


**Q: Can I install the INWALL ABS BUTTONS myself?**

A: No, these buttons must be installed by licensed and registered tradespeople as per regulations.

**Q: What should I do if there are printing errors in the specifications?**

A: Contact the manufacturer/distributor for clarification and updated information regarding the product specifications.

## Documents / Resources



[R and T 1654677 Giro Matte White ABS Square Inwall Cistern Buttons](#) [pdf] Owner's Manual

1654677 Giro Matte White ABS Square Inwall Cistern Buttons, 1654677, Giro Matte White ABS Square Inwall Cistern Buttons, Matte White ABS Square Inwall Cistern Buttons, Square Inwall Cistern Buttons, Inwall Cistern Buttons, Cistern Buttons, Buttons

## References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.