



[Home](#) » [RadioShack](#) » **radioshack 2604796U Wireless Numeric Keyboard User Guide** 

## Contents [ [hide](#) ]

- [1 radioshack 2604796U Wireless Numeric Keyboard](#)
- [2 Product Specifications](#)
- [3 Features](#)
- [4 Instructions](#)
- [5 FCC](#)
- [6 Frequently Asked Questions](#)
- [7 Documents / Resources](#)
  - [7.1 References](#)



## **radioshack 2604796U Wireless Numeric Keyboard**



## Product Specifications

- Wireless technology: 2.4GHz
- Wireless distance: 10m
- Size: 145\*90\*25mm
- Operating Voltage: 1.5V
- Operating Current: 10mA
- Key Life: 3,000,000 times
- Power supply: 1\*AAA (Alkaline batteries are recommended)

## Features

- Advanced 2.4GHz wireless technology with an effective working distance of up to 10 meters.
- Simple and beautiful appearance, comfortable hand feel and switch-free design, simple and fast.
- Professional numeric keypad. Suitable for finance/accounting/business/securities/banking offices, etc. Suitable size, good office assistant.
- Easily identifiable keys and not easy to fade.
- Easy to install: plug and play, easy to use.
- System supported: Windows 2000/XP/Vista/Windows 7/Windows 8/Windows 10/Linux/mac. Any Changes, expressly or modifications not approved by the party responsible for compliance could void the user's authority to operate the equipment.

## Instructions

1. Insert 1\*AAA battery into the wireless numeric keyboard (Alkaline batteries are recommended).
2. Ensure the power switch is in the ON position.
3. Insert the USB receiver into an available USB port on your computer.
4. The numeric keyboard should automatically connect to your computer once the receiver is inserted.
5. You can now start using the numeric keyboard for your financial, accounting, or other office tasks.



## Product specification

**Plug and Play Simplicity:** Just plug in the tiny USB-A receiver and start working in seconds with a strong, reliable connection to your wireless computer mouse up to 10m

## FCC

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This

equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and the receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

## Frequently Asked Questions

- **Q: What should I do if the numeric keyboard is not working?**  
A: Make sure the power switch is ON, replace the battery with a new one, and reinsert the USB receiver into a different USB port on your computer.
- **Q: Can I use rechargeable batteries with the numeric keyboard?**  
A: It is recommended to use alkaline batteries for optimal performance. Rechargeable batteries may not provide the same level of power output.

## Documents / Resources

	<a href="#">radioshack 2604796U Wireless Numeric Keyboard [pdf]</a> User Guide 2604796U, 2BDUR-2604796U, 2BDUR2604796U, 2604796U Wireless N umeric Keyboard, 2604796U, Wireless Numeric Keyboard, Numeric Keyb oard, Keyboard
---	--

## References

- [User Manual](#)

RadioShack

2604796U, 2604796U Wireless Numeric Keyboard, 2BDUR-2604796U, 2BDUR2604796U, Keyboard, Numeric Keyboard, RadioShack, Wireless Numeric Keyboard

## Leave a comment

Your email address will not be published. Required fields are marked \*

Comment \*

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.