

Rapala®
15lb Touch
Screen
Tourney Scale



Rapala 15lb Touch Screen Tourney Scale Instruction Manual

[Home](#) » [Rapala](#) » Rapala 15lb Touch Screen Tourney Scale Instruction Manual 

Contents

- [1 Rapala 15lb Touch Screen Tourney Scale](#)
- [2 Introduction](#)
- [3 Specifications](#)
- [4 Package Includes](#)
- [5 Features](#)
- [6 Usage](#)
- [7 Care and Maintenance](#)
- [8 Troubleshooting](#)
- [9 FAQs](#)
- [10 References](#)
- [11 Related Posts](#)

Rapala®

Rapala 15lb Touch Screen Tourney Scale



Introduction

A high-performance digital scale made for anglers, especially those who are competing in events, the Rapala 15lb Touch Screen Tourney Scale. This scale can hold up to 15 pounds (6.8 kg), and its accuracy is very good, with a precision of 0.05 pounds. This means that you can get accurate weight readings for both small and big catches. The scale has a touch screen display that makes it easy to use and gives you quick access to different functions. It also has a memory function that lets you save up to 10 weight readings, which makes it perfect for use in tournaments. You can weigh fish in containers with the tare function, and the auto-off function saves battery life. This scale is made to be water-resistant, so it can handle wet conditions, making it good for fishing trips outside. The Rapala scale is reliable and easy to use in all fishing situations. It has a strong stainless steel hook and a big digital screen.

Specifications


- **Model:** Rapala 15lb Touch Screen Tourney Scale
- **Weight Capacity:** 15 lbs (6.8 kg)
- **Precision:** 0.05 lbs (approximately 23 g)
- **Display:** Touch screen with large, clear backlight
- **Units of Measurement:** Pounds (lbs) / Kilograms (kg)
- **Power Supply:** 2 x AAA batteries (included)

- **Material:** Durable plastic with a stainless steel hook
- **Dimensions:** 5.5 x 3.5 x 1.25 inches (140mm x 90mm x 32mm)
- **Weight:** 0.5 lbs (approximately 227 grams)
- **Battery Life:** Up to 50 hours of continuous use
- **Additional Features:** Tare function, auto-off feature, overload indicator, memory storage for 10 weights, data lock function
- **Warranty:** 1-year limited warranty

Package Includes

- Rapala 15lb Touch Screen Tourney Scale
- 2 x AAA batteries
- User Manual
- Protective pouch for storage

Features



- **A 3 Weight Display Options** Choose 1b./0z., decimal lbs. or kg,
- **B 8 Storage Bins** Store up to 8 individual fish weights.
- **C Total Catch Weight** Continuously displays the total weight stored in bins.
- **D Back Light** Illuminates the screen for low light and evening conditions.
- **E Ambient Temp** Displays current air temperature.
- **F Sound** Turn acknowledgment tone on or off.

1. TURN ON AND CHOOSE PREFERRED MEASURING UNITS (A)

(00 Lb. 000z °F/ 00.00 Lbs. °F/ 00.00 Lbs. °C/ 00.00 Kg °F/ 00.00 Kg °C)

- Press the POWER button for 3 seconds (until the screen flashes)
- While the screen is flashing press the POWER button to cycle through the units.
- When desired units are shown on the display wait until flashing stops. Next time you turn on your scale the chosen unit will be set as default.

2. ADJUST SCALE TO ZERO

Press the CLEAR SCALE button on the touch screen.

3. TURN ON OR OFF BACKLIGHT (D)

Press the LOCK/LIGHT button until the backlight turns on or off.

4. TURN ON OR OFF BEEP SOUND (F)


Press the SOUND icon button until you hear a beep sound .

5. MEASURE THE WEIGHT OF A FISH

- Add fish to the scale using the clip or hook.
- The weight of the fish will show on the display.

6. STORE A WEIGHT IN STORAGE BIN (B)

After the fish is on the scale and the weight of the fish is showing on the display:

- Press the LOCK/LIGHT button once. You will see the  flashing,
- Press the desired storage bin (1-8) to save the weight.
- Weight will be shown in the selected bin.

7. DELETE WEIGHT STORED IN BIN (B)

- Press the UNDO button and the desired bin at the same time.
- The CLEAR SCALE button will be flashing,
- Press the CLEAR SCALE button to delete the bin.

8. DELETE ALL BINS (B)

- Press the POWER button and the CLEAR SCALE button at the same time
- All the storage bins will flash
- Press the CLEAR SCALE button to delete all bins.

Requires 2 AA batteries(batteries not included).



Usage

1. **Turn On:** Press and hold the power button to turn on the scale.
2. **Select Unit of Measurement:** Use the touch screen to toggle between pounds (lbs) or kilograms (kg).

3. **Weighing Items:** Hang the fish or object securely on the stainless steel hook, ensuring the item is fully supported before taking the measurement.
4. **Store Weights:** The scale allows you to store up to 10 weights for easy reference, especially useful for tournament conditions.
5. **Tare Function:** If you need to weigh an item in a container, use the tare function to subtract the weight of the container.
6. **Reading Display:** Read the weight from the clear, backlit touchscreen display.
7. **Turn Off:** The scale will automatically shut off after 5 minutes of inactivity to save battery.

Care and Maintenance

- **Clean the Scale:** Use a soft cloth to wipe down the scale after each use. Avoid using harsh chemicals that could damage the surface or display.
- **Drying:** Always ensure the scale is dry before storing it, especially if it has been exposed to water or humidity.
- **Battery Maintenance:** Replace the batteries when the display begins to dim or the scale stops turning on. Always use the recommended battery type (AAA).
- **Storage:** Store the scale in a dry, cool place to avoid corrosion or damage. Keep it in the protective pouch to protect it from dirt, scratches, and impacts.
- **Check Hook:** Regularly inspect the hook for wear and tear. If the hook becomes bent or damaged, it may need to be replaced to ensure accurate weighing.

Troubleshooting

- **Scale Won't Turn On**

Ensure the batteries are installed correctly and have sufficient charge. Replace the batteries if necessary.

- **Inaccurate Readings**

Make sure the scale is properly zeroed before use. You can reset it by pressing the tare button while the scale is empty. If the item is swinging while being weighed, hold it steady for a more accurate reading.

- **Display Flickers or Dims**

Check the battery charge and replace the batteries if necessary. Also, ensure there is no debris obstructing the display or buttons.

- **Overload Indicator Appears**

If the weight exceeds the 15 lbs limit, the overload indicator will appear. Ensure the object being weighed does not exceed the maximum weight capacity.

- **Touch Screen Not Responding**

Ensure that the screen is clean and free of moisture or dirt. Gently clean the touch screen with a microfiber cloth.

FAQs

What is the maximum weight capacity of the Rapala 15lb Touch Screen Tourney Scale?

The Rapala 15lb Touch Screen Tourney Scale has a maximum weight capacity of 15 lbs (6.8 kg), making

it suitable for weighing a variety of fish.

How precise is the Rapala 15lb Touch Screen Tourney Scale?

The scale provides high accuracy with a precision of 0.05 lbs (approximately 23g), ensuring reliable and accurate weight measurements.

What type of display does the Rapala 15lb Touch Screen Tourney Scale have?

The scale features a touchscreen display, providing an intuitive interface for switching between weight measurements and other functions.

Is the Rapala 15lb Touch Screen Tourney Scale water-resistant?

The Rapala 15lb Touch Screen Tourney Scale is water-resistant, making it ideal for use in wet conditions, such as during rain or around water.

What type of hook is used on the Rapala 15lb Touch Screen Tourney Scale?

The scale includes a sturdy stainless steel hook, ensuring secure attachment of your fish or items during weighing.

What is the function of the overload indicator on the Rapala 15lb Touch Screen Tourney Scale?

The overload indicator alerts you when the weight exceeds the scale's maximum capacity, preventing potential damage to the scale.

What are the different weight units available on the Rapala 15lb Touch Screen Tourney Scale?

The Rapala 15lb Touch Screen Tourney Scale offers multiple weight units such as pounds, kilograms, and ounces, allowing you to switch based on your preference.

Download this Manual: [Rapala 15lb Touch Screen Tourney Scale Instruction Manual](#)

References

- [User Manual](#)

Manuals+. Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.