

RAYNESYS 3 In 1 Collapsible Wagon Cart with Wheels Instruction Manual

Home » Raynesys » RAYNESYS 3 In 1 Collapsible Wagon Cart with Wheels Instruction Manual



Contents

- 1 RAYNESYS 3 In 1 Collapsible Wagon Cart with
- 2 Raynesys Folding Wagon Cart Assembly Instruction
- **3 Unfolding Instructions**
- **4 Storing Instructions**
- **5 Product Feature:**
- **6 Product Parameters**
- 7 Documents / Resources
 - 7.1 References
- **8 Related Posts**



RAYNESYS 3 In 1 Collapsible Wagon Cart with Wheels



Product Specifications

Unfolding Size: 91*47*56CMFolding Size: 27.5*20*56CM

• Volume: 4 CU FT / 120 L

Product Weight: 11 LBS / 5 KGBearing Load: 220 LBS / 100 KG

Unfolding

- 1. Push 4 wheels into shaft securely. (Press the red button to remove and replace, the front wheel bracket with brake button).
- 2. Pull out 4 corners in all directions and press 2 frames (A) to unfold the wagon.
- 3. Pull handle out to extend.

Storing

1. Press the button at the handle shaft base and retract the handle.

Product Features

- Replaceable Fabric
- Removable Wheels
- · Automatic Rebound Handle

Warnings

- Please keep the load weight BELOW 220 LBS.
- Please do not immerse in water for a long time.

- The wagon is NOT DESIGNED for pulling forward or pushing back for stopping.
- The wagon is NOT RECOMMENDED for use in the opposite direction.

FAQ

- 1. Q: Can I replace the fabric on the wagon?
 - A: Yes, the fabric on the wagon is replaceable.
- 2. Q: What is the maximum weight capacity of the wagon?
 - A: The maximum bearing load is 220 LBS or 100 KG.
- 3. Q: How do I store the wagon?
 - A: To store the wagon, press the button at the handle shaft base and retract the handle.

Raynesys Folding Wagon Cart Assembly Instruction

Parts List

- 1. 1 x Cart Frame
- 2. 4 × Wheels
- 3. 1 x Bottom Plate

Unfolding Instructions

- 1. Take out all cart accessories from the carton.
- 2. Push 4 wheels into shaft securely. (Press the red button to remove and replace, the front wheel bracket with brake button).
- 3. Pull out 4 corners in all directions and press 2 frames (A) to unfold the wagon.



- 4. Place the bottom plate into the cart and lay it flat.
- 5. Pull handle out to extend.





Storing Instructions

- 1. Remove the bottom plate from the cart.
- 2. Press the button at handle shaft base and retract the handle.
- 3. Pull the rope (B) to fold the cart up.







- 4. Tightly squeeze and fold the cart inward.
- 5. Wrap and tighten the cart with the strap.
- 6. Finish and pull out the strap to lift the cart.







Product Feature:

- 1. Replaceable Fabric
- 2. Removable Wheels
- 3. Automatic Rebound Handle







Product Parameters

Unfolding Size: 91*47*56CM	Product Weight: 11 LBS / 5 KG
Folding Size: 27.5*20*56CM	Bearing Load: 220 LBS / 100 KG
Volume: 4 CU FT / 120 L	

Warning

- 1. Please keep the load weight BELOW 220 LBS to avoid affecting the normal use of the wagon!
- 2. Please do not immerse in water for a long time. In special circumstances, please dry the product as soon as possible after wading to avoid reducing its usage cycle!
- 3. The wagon is NOT DESIGNED for transporting the children or adults!
- 4. The wagon is NOT RECOMMENDED to be used for downhill road condition. If necessary, please tilt the draw bar to pull the wagon or push it back to stop!
- 5. When the cart is loaded, the handle is only suitable for pulling forward. Please do not use it in the opposite direction to avoid unnecessary damage!

Thank You for Your Order

Dear Customer,

Words cannot express how grateful we are that you have chosen Raynesys! Our Raynesys is, and always has been, committed to providing users with

If you have any questions about Raynesys Wagon, please scan the QR code below and write down your questions, or you can send the relevant questions

May all the goodness and warmth come as it should! Looking forward your next visit and sincere suggests.

E-mail: cs@iraynesys.com



Documents / Resources



RAYNESYS 3 In 1 Collapsible Wagon Cart with Wheels [pdf] Instruction Manual 3 In 1 Collapsible Wagon Cart with Wheels, Collapsible Wagon Cart with Wheels, Wagon Cart with Wagon Cart with Wheels, Wagon Cart with Wagon Cart

References

User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.