

How to use Chroma Studio in Synapse 3

[Home](#) » [Razer](#) » How to use Chroma Studio in Synapse 3 


Contents

- [1 Use Chroma Studio in Synapse 3](#)
- [1.1 Related Posts](#)

Use Chroma Studio in Synapse 3

The Chroma Studio section enables you to create and edit your own Chroma Effects which you can apply to all supported Razer Chroma-enabled devices.

1. Open Razer Synapse 3 and navigate to “STUDIO” from the top tab.




2. There are several options to use in Chroma studio:
 1. Effect layer – The added effects can be seen in this section.
 2. Add Effect – Under this section, you select your desired effect.
 3. Add Group – This option creates a group for your effect layers.
 4. Duplicate effect – This option duplicates the selected effect.
 5. Delete effect – This option deletes the selected effect.
 6. Quick Selection – It is a dropdown menu with presets to easily customize your Razer devices.
 7. Chroma Profile – This shows the Chroma Profile you are working or editing on.
 8. Tools – This shows tools for selection and editing.
 9. Undo / Redo – Undos and redos your recent actions.
 10. Effect settings – This column shows numerous settings for the lighting effects such as color, speed, and

more.

11. Save – Click it to save your settings.

For more information, refer to [Chroma Studio's Online Master Guide](#).



To learn how to add or remove an effect, refer to [How to add lighting effects on Razer Synapse 3 Chroma Studio](#) and [How to remove Chroma effects on Razer Synapse 3](#), respectively.

Manuals.