

## RAZER Intel Chipset Driver Version 10.1.16.7. Installation Guide


[Home](#) » [Razer](#) » RAZER Intel Chipset Driver Version 10.1.16.7. Installation Guide 

### Contents

- [1 RAZER Intel Chipset Driver Version 10.1.16.7](#)
- [2 DRIVER INSTALLATION INSTRUCTIONS](#)
- [3 INSTRUCTIONS](#)
- [4 INSTALLATION PROCESS](#)
- [5 Documents / Resources](#)
- [6 Related Posts](#)



**RAZER Intel Chipset Driver Version 10.1.16.7**



## DRIVER INSTALLATION INSTRUCTIONS

### APPLICABLE MODEL NUMBERS

- RZ09-03137
- RZ09-03138

### DRIVER NAME AND VERSION

Intel Chipset Driver Version 10.1.16.7

### INSTRUCTIONS

**Note:** This download is for the original driver that was installed on your Razer Laptop. Updates for this driver are available via standard Windows Updates. To ensure you have the latest driver installed on your Blade please make sure to apply all available updates from Windows.

Please follow the instructions below to download and install the original driver for your Blade. Following the installation, it is recommended to search for any available Windows Updates.

1. Ensure that your Blade is plugged into a wall outlet and not running on battery alone before proceeding.
2. Save any open documents on your computer and close all other programs before attempting this update.
3. Download the driver from the link You will need to right click the .zip folder and choose to extract the files to location of your choosing (such as your desktop) to locate the files for the installation process.

<http://rZR.to/zwQsQ>

4. Once you have extracted the file proceed to the installation steps below.

### INSTALLATION PROCESS


1. To initiate the initial process, double-click on "SetupChipset.exe" (Application) as shown in the image below:

Name	Size	Packed	Type	Modified	CRC32
..			File folder		
DriverFiles			File folder	2/7/2019 11:42 ...	
mup.xml	725,690	12,743	XML Document	4/5/2019 3:41 ...	5B0DB754
SetupChipset.exe	2,948,832	2,689,958	Application	4/5/2019 3:41 ...	E2BF4526
WixLicenseNote.txt	3,415	1,307	Text Document	4/5/2019 3:39 ...	29F73552

- The Intel® Chipset Device Software will prompt you to exit all other programs. Once done with the message, click "Next".




- A license agreement will appear on the screen. Read the terms of the agreement and once done, click "Accept".




- A confirmation of the Installation will appear, click "Install".

## Intel(R) Chipset Device Software

### Readme File Information



5. The User Account Control window may pop up to confirm changes that will be made by the Click "Yes" to allow the application to launch.
6. A progress bar will appear indicating the status and progression of the installation Do not interrupt the installation process.
7. Once the progress bar reaches 100% completion, you will be prompted to pick either Restart your Razer Blade now or later. Select when to restart your Razer Blade. Once your Blade has restarted your system will be updated.





## Documents / Resources

<div><p><b>DRIVER INSTALLATION INSTRUCTIONS</b></p><p><b>APPLICABLE MODEL NUMBERS</b></p><p>• RZ09-03137 • RZ09-03138</p><p><b>DRIVER NAME AND VERSION</b></p><p>Intel Chipset Driver Version 10.1.16.7</p><p><b>INSTRUCTIONS</b></p><p>Before installing the driver, please ensure that your computer is connected to the Internet. The driver is downloaded from the Razer website. Please ensure that your computer is connected to the Internet before installing the driver.</p><p>Please follow the instructions below to install the driver. Please ensure that your computer is connected to the Internet before installing the driver.</p><ol style="list-style-type: none"><li>1. Download the driver from the Razer website.</li><li>2. Run the driver installer.</li><li>3. Follow the on-screen instructions to complete the installation.</li><li>4. Restart your computer.</li></ol><p><b>NOTES</b></p><p>Please ensure that your computer is connected to the Internet before installing the driver.</p></div>	<p><a href="#">RAZER Intel Chipset Driver Version 10.1.16.7.</a> [pdf] Installation Guide RAZER, RZ09-03137, RZ09-03138, Intel, Chipset, Driver, Version 10.1.16.7.</p>
--	---