

Razer Pro Type Manual and FAQ

Home » Razer » Razer Pro Type Manual and FAQ

Contents [hide

- 1 Razer Pro Type Support
- 2 FAQ
 - 2.1 At a Glance: Razer Pro Type
 - 2.2 Device Layout
- 2.3 Technical Specifications
- 3 How To
 - 3.1 How do I connect the Pro Type to a host for the first time?
 - 3.2 How do I switch between profiles?
 - 3.3 How do I know which profile is active?
 - 3.4 What do the battery LED indicator colors mean?
 - 3.5 How to switch connectivity mode of the Razer Pro Type?
- 4 Troubleshooting
 - 4.1 When the keyboard is paired to my laptop via Bluetooth, the connection intermittently cuts in and out. How do I fix this?
 - 4.2 My Pro Type keyboard has suddenly stopped responding
 - 4.3 Software & Downloads
 - 4.4 Do I need to install additional software or drivers to use the Razer Pro Type?
 - 4.5 Downloads
 - **4.6 Related Posts**

Razer Pro Type Support



FAQ


At a Glance: Razer Pro Type

A big part of producing top-quality work comes from the quality of your office equipment—so why settle for anything less? Take your productivity to the next level with a wireless keyboard that offers a superior typing experience, engineered for the optimal balance of performance and comfort. The Razer Pro Type | RZ03-03070 is built to keep up with the rigors of demanding office work and is well-suited to deliver consistent, reliable performance over long periods of intense use.





Device Layout



- A. Volume control keys
- B. Media keys
- C. Backlight control keys
- D. Sleep mode key
- E. Reset button
- F. Type C charging-only port
- G. Mode switch (2.4 / OFF / BT)

- H. Power indicator
- I. LED indicators*
- J. Magnetic USB dongle compartment
- K. Kickstand

Technical Specifications


^{*}Limited functionality on selected devices.

Keyboard Type	Full-sized Mechanical Keyboard with soft-touch coating		
Design	Metal top cover		
Available switch type(s)	Razer™ Orange Mechanical Switch		
Wireless Connectivity	2.4GHz / Bluetooth		
Multi-hosts connection	Up to 4 devices		
Battery Life	With backlighting on: Up to 12 Hrs. on Bluetooth and 2.4GHz With backlighting off: Up to 84 Hrs. on Bluetooth and 78 Hrs. or		
Backlighting	White LED Backlit keys		
Key Roll-over	10-key roll-over		
Gaming Mode	No		
Fully Programmable Keys	Yes		
Synapse	Synapse 3		
On-the-Fly Macro Recording	No		
1000Hz Ultrapolling	No		
Additional Game Keys	No		
Audio Pass-Through	No		
Dedicated Media Controls	Yes		
USB Pass-Through	No		
Wrist Rest	No		
Cable Type	2m Detachable braided fiber cable		
Approx. Dimension LxWxH (mm)	442 mm x 133 mm x 39 mm		
Approx. Weight (grams)	900g		

How To

How do I connect the Pro Type to a host for the first time?


1. Set the mode switch to BT.



2. Up to 3 Bluetooth devices can be paired and registered to your keyboard (one for each profile). To activate the pairing mode of your preferred profile, press and hold its corresponding shortcut for 5 seconds. The LED indicators will then display which Profile has been activated.


Shortcut	Profile	Status		
fn + 1	Profile 1		• •	o a
fn + 2	Profile 2	o	·	°
fn + 3	Profile 3			

3. Enable Bluetooth on the host device and select Razer Pro Type from the list of devices found. The device will pair with your keyboard and the connection will be registered on the active profile.



How do I switch between profiles?

To switch between any of the Bluetooth profiles available on your keyboard, simply press the corresponding shortcut of the profile your device is registered to.



How do I know which profile is active?

The LED indicators will display which profile is currently active while the fn key is pressed

What do the battery LED indicator colors mean?


Below are the Power Indicators status based on the Razer Pro Type | RZ03-03070 battery.

Mode	Charged	Low	Critical*
2.4 / BT	0	0	*
OFF		0	

^{*}Critical status indicates that the keyboard's battery is less than 3%. The lighting sequence will repeat until the battery has been drained or the keyboard is being charged.

How to switch connectivity mode of the Razer Pro Type?

You can switch the connectivity mode of the Razer Pro Type | RZ03-03070 between 2.4GHz and Bluetooth by switching the toggle as shown below.



Troubleshooting

When the keyboard is paired to my laptop via Bluetooth, the connection intermittently cuts in and out. How do I fix this?

Try updating your Intel drivers by visiting: https://www.intel.com/content/www/us/en/support/intel-driver-support-assistant.html

My Pro Type keyboard has suddenly stopped responding

Please try to recover the keyboard by pressing the reset button using a paper clip for at least 1 second. The reset button is the small hole beside the USB-C port. Pressing the reset button will not erase any of the Synapse 3-configured settings.

Software & Downloads

Do I need to install additional software or drivers to use the Razer Pro Type?

You may use the standard keyboard functions by simply connecting the Razer Pro Type | RZ03-03070 to your computer through either wired, 2.4GHz, or Bluetooth connecting.



Other advanced features can be configured by installing Razer Synapse 3 on your computer or laptop.

Downloads

Razer Pro Type Master Guide (French) - **Download**

Razer Pro Type Master Guide (Japanese) - **Download**

Razer Pro Type Master Guide (Korean) - **Download**

Razer Pro Type Master Guide (Russian) - **Download**

Razer Pro Type Master Guide (Portuguese-Brazilian) – **Download**

Razer Pro Type Master Guide (Simplified Chinese) - Download

Razer Pro Type Master Guide (Traditional Chinese) – <u>Download</u>

Razer Pro Type Master Guide (German) – $\underline{Download}$

Razer Pro Type Master Guide (Spanish) – **Download**

Razer Pro Type Master Guide (English) - **Download**

Manuals+, home

privacy