

 **Razor**
MX350 Control
Module



Razor MX350 Control Module Installation Guide


[Home](#) » [Razor](#) » **Razor MX350 Control Module Installation Guide** 

Contents

- [1 Razor MX350 Control Module](#)
- [2 Specifications](#)
- [3 Product Usage Instructions](#)
- [4 FAQ](#)
- [5 Documents / Resources](#)
 - [5.1 References](#)



Razor MX350 Control Module



Specifications

- **Model:** MX350(V19+), MX400 (16+)

- **Tools Required:**

- Phillips screwdriver,
- 5mm open wrench,
- 8mm open wrench (Not included)

- **Manufacturer:** Razor

CAUTION: To avoid potential shock or other injury, turn power switch OFF and disconnect charger before removing or installing the batteries. Failure to follow these steps in the correct order may cause irreparable damage.

Product Usage Instructions

1. Step 1: Removing Old Control Module

1. Twist the black plastic cap and remove (See insert).
2. Using a 5mm Allen wrench, remove the hex bolt.




Figure 1

2. Step 2: Removing Fairing

1. Using a 5mm Allen wrench, loosen the two hex bolts underneath the rear of the seat.
2. Remove the fairing.



Figure 2

3. Step 3: Removing Battery Cover

On the opposite side of the charger port, locate and remove the 5 Phillips screws and locknuts on the battery cover using a Phillips head screwdriver and 8mm open wrench. Separate and remove cover.




Figure 3

4. Step 4: Disconnecting Old Control Module

Carefully cut the zip tie holding the wires together. Disconnect the five white plastic connectors attached to the control nodule by depressing the tab (see insert).




Figure 4

5. Step 5: Removing Old Control Module

Using a Phillips head screwdriver, loosen the two screws holding the control module in place and remove.



Figure 5

6. Step 6: Installing New Control Module

Install the new control module using the same two screws previously removed. Reconnect the five white plastic connectors.




Figure 6

7. Step 7: Final Steps

Reverse steps:

1. Reattach the battery cover using the same five screws and locknuts previously removed.
2. Reattach fairing and plastic cap.

Attention: Charge the unit for at least 18 hours before riding.

NOTE: If you received a control module AND throttle, make sure to replace BOTH parts on your unit


Need Help? Visit our website at www.razor.com or call toll-free at **866-467-2967** Monday – Friday 8:00am – 5:00pm Pacific Time

FAQ

Q: What should I do if I encounter difficulties during installation?

A: For assistance, visit our website at www.razor.com or call toll-free at **866-467-2967** Monday – Friday 8:00am – 5:00pm Pacific Time.

Documents / Resources

	<p>Razor MX350 Control Module [pdf] Installation Guide MX350, MX350 Control Module, Control Module, Module</p>
-------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------

References

- [Razor | Scooters and Ride-ons for the whole family](#)
- [User Manual](#)

[Manuals+](#) [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.