

REDRAGON K611 Mechanical Gaming Keyboard Instruction Manual

Home » REDRAGON » REDRAGON K611 Mechanical Gaming Keyboard Instruction Manual



Contents

- 1 REDRAGON K611 Mechanical Gaming
- **Keyboard**
- **2 Functions**
- 3 FAQ
- **4 FCC Statement**
- 5 Documents / Resources
- **6 Related Posts**



REDRAGON K611 Mechanical Gaming Keyboard



OS Support

WinXP/Vista/Win7/Win8/Win 10/Win11

Functions

- 1. Computer USB port interfaces with the keyboard without needing the installation of additional drivers or software.
- 2. Multi-level backlight brightness
 - 1. Press and hold the [FN] key, and then press the arrow key" "to increase the backlight brightness of the keyboard.
 - 2. Press and hold the [FN] key, and then press the arrow key" "key to decrease the backlight brighness of the keyboard.
- 3. Breathing and rotate speed
 - 1. Press and hold the [FN] key, and then press the arrow key"-"to slow down.
 - 2. Press and hold the [FN] key, and then press the arrow key">"keys to speed up.
- 4. Selectable backlight modes
 - 1. Press and hold the [FN] key, and then press the INS (M) key to switch between the 9 modes
- 5. FN function key for backlight gaming modes
 - 1. FN+1 (L1): First Person Shooter (FPS) Mode ESC, W, A, S, D, 1,
 - 2. FN+2 (L2): Cross Fire (CF) Mode Q,W, E, R, A, S, D, G, B, 1, 2, 3, 4, 5, Space, L-Ctrl, L-Shift, L-Alt, Tab, F1, F2, F3, Home, End, PgUp, PgDn, PrtSc, Scrlk
 - 3. FN+3 (L3): Call of Duty (COD) Mode Q,W,E, R, T,A, S, D, F, G, C,V, 1,2, 3, 4, 5,6,7, L-Ctrl, L-Shift
 - 4. FN+4 (L4): Real Time Strategy (RTS) Mode .Q,W, E, R, T, Y, U, P, A, S, D, F, G, H, K, L, Z, X, N, M, Space, L-Ctrl, L-Shift, L-Alt 1, 2, 3, 4, 5, 6,7,8,9,0
 - 5. FN+5 (L5): LOL/DOTA Mode Q,W,E, R, D, F, G, V, B, L-Ctrl, L-Alt, Tab, Space, ,1,2,3, 4, 5, 6, Esc
 - 6. FN+6 (L6): Racing Mode W, A, S, D, R, 1, , ,LCtrl, L-Shift, L-Alt
 - 7. FN+7 (L7): NBA Mode W, E, R, A, S, F, Z, X, C, V, Space, 1, , ,1,2, 3, 4, L-Shift, L-Ctrl, L-Alt
 - 8. FN+8 (L8): LOL/DOTA Simple Mode O, W,E, R, D, F, B, 1,2, 3,4, 5,6
 - 9. FN+9 (LRI), FN+0 (LR2): Custom Game Modes
 - 10. With these game modes, you can create your own custom lighting schemes for your own needs and preferences.
 - 1. Press FN+9 (LR1) or FN+0 (LR2) to choose which game mode to customize.
 - 2. Press FN+Home (LR) to start recording your custom scheme
 - 3. Press any key to turn on the backlight on the pressed key. Press again to disable backlight on the pressed key.
 - Press FN+End (S) to save your scheme.
 If you want to clear any custom game mode, press FN+PageIUp.
- 6. Swap functions of [WITAIIS|[D] and arrow keys
 - 1. Press and hold the [FN] key, and then press the [W] key to interchange the function of the four letter keys [W]TAJISI[D] and the four arrow keys [TIIT1]
 - 2. Repeat the above operation to restore the previous setting.
- 7. Disabling the Windows [WIN] key
 - 1. To disable the [WIN] key: Press and hold the [FN] key, and then press [WIN] key too turn off [WIN] key in

order to avoid going to desktop while gaming if user presses [WIN] key by mistake.

- 2. Repeat the above operation to restore the function.
- 8. Side light adjustment FN+PAUSE switching among 4 effects
- 9. Multimedia function: 12 multimedia keys. Access by pressing the [FN] key and one of the [F11-F12] keys at the same time.
 - 1. FN+F1:Open My Computer
 - 2. FN+F2: Search
 - 3. FN+F3: Open Calculator
 - 4. FN+F4:Open Media Player
 - 5. FN+F5: Previous
 - 6. FN+F6: Next
 - 7. FN+F7: Play/Pause
 - 8. FN+F8: Stop
 - 9. FN+F9: Mute
 - 10. FN+F10: Lower Volume
 - 11. FN+F11: Raise Volume D FN+F12: Lock Keyboard
 - 1. Press to lock the functions of all keys
 - 2. Press again to unlock

FAQ

- 1. If the keyboard doesn't respond, please check if the keyboards USB cable is correctly inserted into the corresponding USB port on the computer, or try another USB port on the computer.
- 2. If you spill liquid on the keyboard, please unplug the keyboards USB cable from the computer immediately. Wipe off excess liquid and put the keyboard in a dry and ventilated place. Make sure the keyboard is dried naturally before the next use

FCC Statement

measures

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including

interference that may cause undesired operation.

California Proposition 65

WARNING: Risk of Cancer from [Name of one or more chemicals known to cause cancer] And Reproductive Harm From [Name of one or more chemicals known to cause reproductive toxicity] Exposure – www.P65Warnings.ca.gov

Documents / Resources



REDRAGON K611 Mechanical Gaming Keyboard [pdf] Instruction Manual K611 Mechanical Gaming Keyboard, K611, Mechanical Gaming Keyboard

Manuals+,