Manuals+ — User Manuals Simplified.

REDRAGON M719 Invader Wired Gaming Mouse Instruction Manual

Contents

REDRAGON M719 Invader Wired Gaming Mouse

Introduction

Dear user Thank you for you choosing REDRAGON Brand, to protect your rights and for better customer service, we ask that you note our warranty rules.

- Within guaranty period, repair is guaranteed for failure due to electrical circuit problems. Man-made damages, such as disassembly, hard impacts, submersion into water, plugging into improper current or voltage, and damage caused by natural disasters such as fire, flood, or earthquake are not included.
- Consumable parts (such as foot stick) and spare parts replacement are no included in our warranty.

OS support
Windows XP/Vista/Win7/Win8/Win10

Button Instructions

1. Left mouse button.
2. Right mouse button.
3. Scroll wheel (clicked as middle mouse button).
4. Rapid fire button (Defaulted to three rapid clicks of the left mouse button).
5. Side key, defaulted function: Forward.
6. Side key, defaulted function: Backward.
7. DPI button: The mouse switches between the 5 DPI 500-1000-2000-3000-5000.
8. Light mode toggle key: The mouse switches between the 7 light modes with each click. Bottom Instructions
9. User mode toggle key: The mouse switches between the 5 user modes with each click.
10. Teflon foot pads: Large wear-resistant materials let the mouse move more smoothly.

Chroma lighting effects
Breathina/Rainbow/Full lightedWave/ao without trace/reactive/flash/off

Light Instructions

There are 2 transparent lines on both side of the mouse as DPI indicator. The DPI indicator light flashes for three times when DPI button is pressed down each clicks.

- Red – Gear 1 (500 DPI)
- Blue – Gear 2 (1000 DPI)

- Green- Gear 3 (2000 DPI)
- Purple- Gear 4 (3000 DPI)
- Yellow- Gear 5 (5000 DPI)

Software Instructions

- Users can adjust the following settings through the software after downloading and installing it.
- Adjust the DPI of the mouse. Speed (range: 100-10000 DPI).
- Macros: Record up to59actions and trigger with one click.
- Lighting: Adjust mouse lighting options.
- Customize 7 mouse buttons.
- Set 5 different user modes and switch between them with the button on the bottom of the mouse.
- Chroma lighting: 7 lighting effects for options.

FAQ

1. If the mouse is not responding, please check whether the mouse is plugged correctly in the corresponding computers USB port, or try another USB ports.
2. If the mouse is moving slowly, jumping or with delay, please try another surface. Dark, dirty, un-flat, bright surfaces may affect the performance of mouse. Mouse pad strongly recommended.

Documents / Resources

REDRAGON M719 Invader Wired Gaming Mouse [pdf] Instruction Manual
M719, Invader Wired Gaming Mouse, Wired Gaming Mouse, Gaming Mouse