

Redtiger F7N DashCamTalk User Manual

Home » Redtiger » Redtiger F7N DashCamTalk User Manual





Contents

- 1 INTRODUCTION
- 2 Meeting Your F7N
- **3 F7N Power Tools**
- **4 Setting Up Your Camera**
- **5 Playing Back Your Media**
- **6 Customizing Your F7N**
- 7 Parking Mode (Optional)
- 8 Connect to the Redtiger App
- 9 GPS Player (PC)
- 10 Mount your camera
- 11 Maintenance
- 12 Trouble Shooting
 - **12.1 WIFI CONNECTION GOES**
 - **WRONNG**
 - 12.2 OTHER PROBLEM
 - **12.3 OTHER PROBLEM**
 - 12.4 RECEIVED DEAD CAMERA?
 - 12.5 ULTIMATE SOLUTION
- 13 Customer Service
 - **13.1 WORDS FROM HEART**
- 14 Documents / Resources
- **15 Related Posts**

INTRODUCTION

WARNING: Be careful when using your camera and its accessories. Always be caution of your surroundings to avoid Injuring yourself and others.


Make sure to follow all local laws including all privacy laws which may restrict recording in certain areas.

Meeting Your F7N


- 1. Screen
- 2. GPS Mount
- 3. Status Light




- 4. Up/ WIFI Button
- 5. Mode/ Confirm Button
- 6. Down / Button



- 7. Power Button
- 8. Micro SD™ Card Slot



- 9. AV-In
- 10. USB Power Slot



11. Reset Button




12. Lens



F7N Power Tools

1. Cig Charger ~ (No Battery Protection)



2. Hardwire Kit (Parking Mode Needed) (Extra charge)



Setting Up Your Camera

INTROTOF7N

Trustful Dashcam that guarding each ridding of yours. UPDATING YOUR CAMERA'S SOFTWARE To get the latest features and best performance from your camera, make sure it's using the most current software.

- 1. Visit <a href="https://www.redtigercam.com/pagesffirmware:11!m<!ale-
 - 1. Update guide POP-UP: Keep your SD card in good condition by reformatting it regularly. This will erase all of your media, so be sure to save it first.





- 1. Press M button and entre Settings
- 2. Press UP button > Format> OK



WARNING: This product is for DC 12v / 24v ~ only.

SD CARD

With your camera off, insert the SD card into the card slot with the label facing the back of your camera. You can eject the card by pressing it into the slot with your fingernail.

WIRING SET UP

Connect your camera to a Cig charger using the included cig charge cable.

SD CARD

You'll need a micro SD card (sold separately) to save your videos and photos. Use a U3 Class 10 SD™ Card dedicated or your camera may malfunction.

SD cards can degrade over time and affect your camera's ability to save your media. Try swapping out an older card for a new one if you're having any problems.

POP-UP: Want to know what software version you're using? Here's where you can find out.

- 1. Press M button and entre Settings
- 2. Press UP button> Version

POWERING ON





POWERING OFF

Press and hold button or 3 seconds to turn it of.




POP-UP:

Short press > Front and Rear View> Front Only> Rear Only > Lock Screen > Screen Display Off

Playing Back Your Media

CHOOSE YOUR MODE

Press M button to entre Recording>Playback>Setting. Video mode will be auto-select when power on .



PLAYBACK

F >> Front Camera R >> Rear Camera



POP-UP:

- > Auto record in 30s none action
- > Long press UP to Turn On WiFi
- > Short press up to lock video
- > Short press DOWN to Capture a movement
- > Long press down to stop/play recording

PALYBACK

Short press M button to see your records.

When select a record > Long press M button 3s to edit your records.



POP-UP: Urgent Locked video will be created by camera sensed a collision or vibration (G-sensor on). It can't be auto-recover but only format to save the important moment.

Select Lock Video to unlock and delete.

You can turn off G-sensor to avoid Locked Records.



POP-UP: Urgent Locked video will be created by camera sensed a collision or vibration (G-sensor on). It can't be auto-recover but only format to save the important moment.


Select Lock Video to unlock and delete.

You can tum off G-sensorto avoid Locked Records.

Customizing Your F7N

SETTINGS

Short press to entre Settings menu.



Resolution

> 2160P @30FPS

> 1440P @60FPS

> 1080P @120FPS

Audio > Sound Recording ON/ OFF

Date Stamp > Stamp ON / OFF

Loop recording > 1 / 3 / 5 mins

G-sensor > Off I Low I Medium/ High

Fatigue Driving > A Reminder Will be Made During Speed Stamp 1h / 2h / 3h / 4h / off **GPS Stamp** > Stamp ON / OFF> Stamp ON / PFF

SETTINGS



Speed Units > KMH/MPH
GPS Info > Display GPS signal strength
Rear Cam Flip > Vertical Flip Your Rear View
Mirror Flip > Horizontal Flip Your Front View
APP > A QR Code for Redtiger app
WiFi > WiFi ON/ OFF
Language > Choose Your Prefer Language
Time Format > 12h/24h



Date/Time > Up Date With GPS

Time Zone > Choose Your Time Zone


Time Zone > Choose Your Time Zone

Frequency > 60HZ/50HZ Click Tone > ON/Mute

Screen Saver > Screen Go Off After 10s I 20s 12mins

Parking Mode > G-sensor I Time-Lapse

Format-Reminder > Remind to Clear Data I Prompt formatting



SD Card Format > Clear SD card data Card-Speed> Card Speed Detection Default Setting> Reset All Settings Version > Software Version

POP-UP: In order to a Clean, Smooth, Comfortable using experience, we suggest you format your SD card once a month.

Parking Mode (Optional)


PREPARE YOUR HARDWIRE KIT

Since we considered some customers have no need of Parking Mode, there's no hardwire kit included in your packages. You could refer this line of words to contact us to get a free hardwire kit.

GETTING TO KNOW YORU HARDWIRE KIT

Features:


- > Low Voltage Protection
- > Multi Input Power
- > Universal Compatibility
- > Length: 11.5ft



WARNING: Wrong connection may disable Voltage Protection and damage your car.

INST ALL YOU HARDWIRE KIT

Red wire >> ACC >> power off along the car Yellow wire >> B+ >>> never power off Black wire >> Ground e.g. screw



SELECT PARKING MODE

Enter Parking Mode In Settings Setting >> Parking Mode

» off/ G-sensor I Time-Lapse 12h / Time-Lapse 24h / Time-Lapse 48h

G-SENSOR

- > Caroff
- > "ACC disconnected" pop-up
- > Collision or vibration be detected
- > An Unerasable record will be created in Lock space

TIME-LAPSE

- > Select 12h I 24h/ 48h
- > A Record will be created in 1 fps during your parking time
- > 1 min= actual 12 mins
- > Collision or vibration be detected
- > An Unerasable record will be created in Lock space

POP-UP: You could usually find your fuse box under the trunk or steering device. You could cut the head of wires and connect it to your fuse directly if your fuses is small.

POP-UP: 1 fps= 1 image during 1 second.

G-sensor could be activated by a deceleration zone.

WRONG INST ALL ED

Connection	Driving	Parking	
ACC B+ Ground	ON	Parking Mode	Right
ACC No connection	OFF	OFF	Wrong
ACC ACC Ground	ON	OFF	Wrong
B+ ACC No connecti on	OFF	OFF	Wrong
No connection Any power Ground	OFF	OFF	Wrong
B+ ACC Ground	ON	OFF	Wrong

PARTICULAR WRONG CONNECTION

Connection	Driving	Parking
B+		
B+	ON	Always On
Ground		

The camera will run Parking Mode normally, but your car battery will be ran out under this connection.

> The Parking Mode will normal working in screen off status. Unless there is a collision or vibration triggered G-Sensor

> Please check if your camera working after 15mins your car is off.

Connect to the Redtiger App

DOWNLOAD APP

- 1. Download our App from: bttps://www.redtigercam.com/pages/app
- 2. Scan QR Code from your F7N
- 3. Download from Apple APP Store or Google Play Store



Teleporl to WiFi operation: https://youtu.be/_NgPEb_G14c



CONNECT YOUR F7N



WiFi Password: 12345678 > Connect Only This Time

POP-UP: This is to avoid series connection between different device.

Some device may prompt that the software contains virus, you could run the installation as an administrator to download App.

ENJOY REMOTE CONTROL








Enjoyed Most of Functions on Your phone

GPS Player (PC)

DOWNLOAD GPS PLAYER


Download our GPS Player from website: https://www.redtigercam.com/pages/gps-player








USE YOUR GPS PLAYER




USE YOUR GPS PLAYER



Mount your camera

HOW TO MOUNT YOUR CAMERA



Teleport to F7N & Rear cam Mounting:

> https://youtu.be/d51YN7Zry0



Maintenance

MAINTEN YOUR CAMEAR

Do not directly plug and unplug the cable or SD card, please perform related operations after camera off.

We do not encourage you connection your camera with other hardwire kit, but if you insist to do this, please have a look of those lower than 6V and higher than 2.5A.

Do not expose to the sun for a long time is the best, camera will heat on during its working, any damaged by high temperature will be added to 1 year free replacement warranty.

Trouble Shooting

WIFI CONNECTION GOES WRONNG

Connection Prepare

- > Mobile data/ VPN is off
- > 16 ft less close to your F7N
- > Only allowed 1 device connection

Connection Notice

- > WiFi password: 12345678
- > Connect only this time

WIFI CONNECTION GOES WRONNG

Connection Prepare

- > Mobile data/ VPN is off
- > 16 ft less close to your F7N
- > Only allowed 1 device connection Connection Notice
- > WiFi password: 12345678
- > Connect only this time

OTHER PROBLEM

Won't enter Parking Mode

- > Hardwire kit needed
- > "ACC disconnected pop up, then entre Parking

Mode automatically

- > Blue light on + Red light flash Camera always on after Car turned down
- > Wrong connection of Red wire and Yellow wire
- > Please connect red wire with ignition fuse

Mass Storage

- > Use USB cable with Data transfer function, please use USB cable without transfer function Won't enter Parking Mode
- > Hardwire kit needed
- > "ACC disconnected pop up, then entre Parking

Mode automatically

- > Blue light on + Red light flash Camera always on after Car turned down
- > Wrong connection of Red wire and Yellow wire
- > Please connect red wire with ignition fuse

Mass Storage

> Use USB cable with Data transfer function, please use USB cable without transfer function

OTHER PROBLEM

Screen Resolution

- > 4K = 2160P = 3840.2160
- > 2.SK = 1440P = 2560*1440 Over Heat
- > Camera could working -4 "F 1 SO"F

RECEIVED DEAD CAMERA?

Use USB cable to connect your camera with computer and check if the screen tum on

- > If not, please unplug sd card and use a pin and press the Reset button at the bottom of camera
- > Reconnect your camera and press 6

ULTIMATE SOLUTION

Use different charging ways to see if the camera work.

- > Use a pin or needle to press the reset button on the bottom of dashcam.
- > Unplug every connection of camera.
- > Plug micro USB charger to see if the camera working. If not, please use your personal USB charge and check again.
- > Check your SD card is U3 Class10, if not, please change or leave message to us to get it.
- > Plug SD card and see if the camera working, if not, please download the latest firmware to solve it.

Please download our latest firmware to upgrade your machine: https://www.redtigercam.com/pages/firmware-

- 1 The upgrade steps are:
- > Download the firmware to the computer.
- > Copy the firmware called "FWQ?OA" to the root directory of the SD card.

- > Insert the SD card into the machine, then insert the power cord and short press the power button (do not tum off the power during this process)
- > During the upgrade process, the blue light is always on and the red light is flashing. After the upgrade is completed, the machine will automatically tum on. i.e. done. You can refer to this video to upgrade: https://youtu.be/IMz1g3O9SPE.

If the method above didn't solve your problem, feel free to contact us and please leave current address which is needed if the camera needs to be replaced later.

► This solution could be dealing with multiple problems> Won't turn on> Restart itself > SD card error > Can't auto recover > Can't playback

Customer Service

WORDS FROM HEART

ince our products are related to the safety of customers, we are committed to product quality and highquality after-sales, we want to achieve the best product quality. In view of no product is flawless, we sincerely believe the true measure of the company's character is what it does *after* its product does not meet expectations, we fee sony for those customers, but deeply grateful for them to make us one more step close to your most trustful auto-mobile after-market brand.

We are willing to provide 1 month free return for your product, 1 year limited warranty, and lifetime technical support. Your product is guaranteed to be free of defects in materials and products from the date of purchase. In addition, you can also exchange your 1 year old product for a discounted price by contacting us on line. Behold the motif of complexity to us, simplicity to others, it's such a pleasure to listen to your advice, and we will take your problem from here.

Redtiger Customer Service Team










Email Mirror Dash Cam Email: support@redtigercam.com Mini Dash Cam Email: help@redtigercam.com

Business Cooperation or others Email: contact@redtigercam.com

> **Customer Phone Service:** +1 888 966 8028 Business Day, Mon-Fri 6 AM-12 AM, 1 PM-8 PM EST(GMT-4)



Documents / Resources



Redtiger F7N DashCamTalk [pdf] User Manual F7N DashCamTalk, F7N, DashCamTalk

Manuals+,