

reMarkable™
reMarkable RM04C Marker Pen



reMarkable RM04C Marker Pen Owner's Manual

[Home](#) » [remarkable](#) » reMarkable RM04C Marker Pen Owner's Manual 

Contents

- 1 Remarkable RM04C Marker Pen
- 2 Specifications
- 3 Product Usage Instructions
- 4 Important information
- 5 FCC Compliance
- 6 ISED Canada Compliance
- 7 Warranty summary
- 8 FAQs
- 9 Documents / Resources
 - 9.1 References
- 10 Related Posts

reMarkable™

Remarkable RM04C Marker Pen



Specifications

- **Model:** RM04C (Marker) / RM05C (Marker Plus)
- **Manufacturer:** reMarkable
- **Address:** Fridtjof Nansens Vei 12, 0369 Oslo, Norway
- **Website:** remarkable.com
- **FCC Compliance:** FCC ID: 2AMK2-RM04CA (Marker) / 2AMK2-RM05CA (Marker Plus)
- **ISED Canada Compliance:** IC: 22859-RM04CA (Marker) / IC: 22859-RM05CA (Marker Plus)
- **EU Compliance:** Directive 2014/53/EU
- **ROHS Compliance:** EU Directive 2011/65/EU with amendment (EU) 2015/863
- **Australia and New Zealand Compliance:** AS/NZS4417 Parts 1, 2, 3, and

Product Usage Instructions

- **Safety Precautions**

Handle the Marker with care. Do not use it for purposes other than its intended use on compatible reMarkable paper tablets. The Marker contains small parts that may pose a choking hazard, so keep it away from children under five years of age.

- **Disposal**

Dispose of the Marker according to local laws and regulations to ensure proper recycling and environmental protection.

- **Regulatory Compliance**

The Marker complies with FCC, ISED Canada, EU, ROHS, Australia, and New Zealand regulations for safe operation and environmental protection.

Important information

- To ensure safe and proper use, please review the safety information below, the user guide (support.remarkable.com), and safety precautions (remarkable.com/legal) before using your reMarkable Marker.
- Handle your Marker with care, and do not use it for anything other than its intended use or on surfaces other than the screens of compatible reMarkable paper tablets. The Marker contains small parts that may present a choking hazard and should not be used by children under five years of age.
- The Marker also contains a lithium-ion battery, active RF transmitters, magnets, and other electronic components. Do not disassemble your Marker or try to modify, remove, or replace any of the parts, as you can permanently damage it and cause harm to yourself or others. Damaged batteries should be treated as hazardous materials. Do not expose your Marker to high external pressure or temperature. Batteries may explode when overheated. The
- The marker should not be subject to any liquid and should not be waterproof. Do not attempt to dry your Marker with an external heat source, such as a microwave oven or hair dryer. Only use your Marker between 0° and 35°C (32° to 95° F), and store it between -10° and 50°C (14° to 122° F). Notice: The built-in battery (model nr. 60340) will stop charging when its temperature exceeds 60°C.
 - RM04C: -42.115 dBuA/m@10m
 - RM05C: -39.805 dBuA/m@10m

Make sure you dispose of your Marker by local laws and regulations.

FCC Compliance

- FCC ID: 2AMK2-RM04CA (Marker)
- FCC ID: 2AMK2-RM05CA (Marker Plus)

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, under Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used by the instructions, it may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. The end user must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must

not be co-located or operating in conjunction with any other antenna or transmitter.

ISED Canada Compliance

- IC: 22859-RM04CA (Marker)
- HVIN: RM04CA (Marker)
- IC: 22859-RM05CA (Marker Plus)
- HVIN:RM05CA (Marker Plus)

This device contains license-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's license-exempt RSS(s). Operation is subject to the following two conditions:

- This device may not cause interference.
- This device must accept any interference, including interference that may cause undesired operation of the device.
- Remarkable declares that this product complies with the essential requirements and other relevant provisions of Directive 2014/53/EU. The full text of the EU declaration of conformity is available at support.remarkable.com.

ROHS Compliance

This product complies with the Reduction of Hazardous Substances (RoHS) requirements in EU Directive 2011/65/EU with amendment (EU) 2015/863

WEEE

- By the European Union's directive (2012/19/EU) on the Waste of Electrical and Electronic Equipment (WEEE), this symbol on the product or its packaging indicates that the product must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. For more information about where you can drop off waste equipment for recycling, please contact your local city office, your household waste disposal service, or the shop where you purchased the product.
- The separate collection and recycling of your waste equipment at the time of disposal will help conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment.

Australia and New Zealand Compliance

- This device complies with the requirements of the electrical and EMC regulations of Australia and New Zealand by AS/NZS 4417 Parts 1, 2, 3, and 4

Warranty summary

- Remarkable warrants that all Remarkable-branded products will be free from material and workmanship defects under normal use by Remarkable's published user manuals and safety information for one (1) year from the date of purchase by the original purchaser for use.
- This limited warranty does not apply to consumable parts, such as reMarkable Marker tips and cables, and

does not cover accidental damage, cosmetic damage, or other faults and issues outside reMarkable's control as a company and manufacturer.

- Remarkable reserves the right to reject any warranty claim from persons failing to provide valid proof of purchase.
- The full terms of our limited warranty and information on how you may contact us to make a claim are available at <https://www.remarkable.com/legal>.
- If you are a consumer, this limited warranty is in addition to mandatory rights that you may have under applicable local consumer protection laws and shall not be construed to exclude, limit, or suspend such mandatory rights, including statutory warranty rights.

FAQS

- **Where can I find the full terms of the limited warranty?**

The full terms of the limited warranty and information on how to make a claim can be found at [remarkable.com/legal](https://www.remarkable.com/legal).

- **Can children under five years old use the Marker?**

No, the Marker contains small parts that may present a choking hazard, so it should not be used by children under five years of age.

- **What surfaces can I use the Marker on?**

Use the Marker only on the screens of compatible reMarkable paper tablets for optimal performance and longevity.

Documents / Resources



[reMarkable RM04C Marker Pen](#) [pdf] Instructions
RM04C, RM04C Marker Pen, Marker Pen, Pen



This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.