

REMOTE PRO BFT Compatible Remotes Instructions

Contents

- [1 REMOTE PRO BFT Compatible Remotes](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 Control Boards](#)
- [5 Programming](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)



REMOTE PRO BFT Compatible Remotes

Product Information

Specifications

- **Brand:** BFT
- **Compatibility:** Deimos slider & Thalia control boards
- **Model:** Compatible Remotes
- **Manufacturer:** www.remotepro.com.au

Product Usage Instructions

Programming your remote to Deimos slider & Thalia control boards

1. Press the OK button 4 times until the screen displays 'Paran'.
2. Press the middle button (-) twice until the screen displays 'Radio'.
3. Press the OK button twice until the screen displays 'Hidden Button'.
4. Simultaneously press the bottom 2 buttons on the remotes until the screen displays 'Release'.
5. Release the 2 buttons.
6. Press any buttons on your new remote to enter programming mode.
7. Test your remote to ensure successful programming.

Programming your remote to NON-LED screen control board

1. Press S1 on the control board of your gate motor to turn on the green light.
2. Simultaneously press the 2 bottom buttons, the green light will stay solid.
3. Press the top left button, the LED light will flash rapidly for about 5 seconds.
4. Test your remote to confirm programming.

Programming your new remote via original remote

1. Hold the 2 bottom buttons on your original working remote until the red LED light turns on.
2. Release the bottom buttons.
3. If the gate moves, stop it with the original remote and restart from step 1.
4. Hold the button that controls your gate until the red LED light turns on, then release immediately.
5. Introduce your new remote within 10 seconds of pressing the last button on the existing remote.
6. Test your remote for functionality.

WARNING

This product may contain a coin/button cell battery. Keep product and batteries away from children. A battery can cause severe or fatal injuries if swallowed or placed inside the body. Seek immediate medical attention if ingestion is suspected.

FAQs

- **Q: What should I do if my gate starts moving during programming?**

A: Stop the gate with your original remote and restart the programming process, ensuring to press the 2 bottom buttons simultaneously.


- **Q: How do I know if my new remote is successfully programmed?**

A: Test your remote after programming by using it to operate the gate. If it functions correctly, it has been successfully programmed.

Control Boards

Deimos slider & Thalia control boards

You control board has a LCD display with 3 buttons



1. Press the OK button 4 times and the screen will display 'Paran'.
2. Press the middle button (-) twice and the screen will display 'Radio'.
3. Press the OK button twice and the screen will display 'Hidden Button'.
4. Press the bottom 2 buttons on the remotes simultaneously and the screen will display 'Release'.
5. Now release the 2 buttons.

6. Press any buttons on your new remote that you would like to operate your gate for 2 seconds.
7. Press the + and – buttons on the control board together 4 times to exit the programming mode.
8. Test your remote.

Programming

Programming your remote to your NON-LED screen control board

1. Press S1 on the control board on your gate motor. The green light on the control board will turn on.
2. Press the 2 bottom buttons simultaneously. The green light will be solid.
3. Press the top left button. The LED light will flash rapidly for about 5 seconds.
4. Test your remote.

Programming your new remote via your original remote

1. Press and hold the 2 bottom buttons on your original working remote simultaneously until the red LED light turns on the remote.
2. Release the bottom buttons.

Please note: If your gate begins moving during this process, stop the gate with your original remote and start again. The reason the gate is moving is because you are not pressing the 2 bottom buttons at the exact same time.


3. Press and hold the button that controls your gate until the red LED light turns on your remote, then release immediately.
4. Introduce your new remote within 10 seconds of pressing the last button on the existing remote.
5. Test your remote.

WARNING

This product may contain a coin/button cell battery. Keep product and batteries away from children. A battery can cause severe or fatal injuries in 2 hours or less if swallowed or placed inside any part of the body. Seek immediate medical attention if it is suspected that a coin/button cell battery has been swallowed or placed inside of any part of the body.

www.remotepro.com.au

Documents / Resources

 <p>BFT Compatible Remotes Instructions</p> <p>Before using BFT compatible remotes:</p> <ol style="list-style-type: none"> 1. Press the 2 bottom buttons simultaneously until the red LED light turns on the remote. 2. Release the bottom buttons. 3. Press and hold the button that controls your gate until the red LED light turns on your remote, then release immediately. 4. Introduce your new remote within 10 seconds of pressing the last button on the existing remote. 5. Test your remote. 	<p>REMOTE PRO BFT Compatible Remotes [pdf] Instructions</p> <p>BFT Compatible Remotes, Compatible Remotes, Remotes</p>
---	---

References

- [R Garage Door Remotes | Car Remotes | Free Shipping AU Wide – Remote Pro](#)

- [R Garage Door Remotes | Car Remotes | Free Shipping AU Wide – Remote Pro](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.