

Remote Pro GDS800 Gate Upgrade Receiver Kit Instructions

Home » Remote Pro » Remote Pro GDS800 Gate Upgrade Receiver Kit Instructions



Contents

- 1 Remote Pro GDS800 Gate Upgrade Receiver Kit Instructions
- 2 Documents / Resources
 - 2.1 References
- **3 Related Posts**

Remote Pro GDS800 Gate Upgrade Receiver Kit Instructions

GDS800 Instructions

www.remotepro.com.au

- 1. TURN OFF POWER OF MOTOR FROM THE POWER POINT
- 2. View the diagram below and ensure that it matches with the top of your motor.
- 3. Connect the black receiver cable to the left side terminal that is labelled WALL SWITCH by pushing the red tab, inserting the black cable and releasing the tab.
- 4. Connect the blue receiver cable to the left side terminal that is labelled COM by pushing the black tab, inserting the blue cable and releasing the tab.
- 5. Connect the brown receiver cable to the terminal that is labelled +24VDC by pushing the red tab, inserting the brown cable and releasing the tab.
- 6. Turn power back on and ensure the receiver powers up.
- 7. Your two new remotes have been pre-programmed to the receiver. Press button 1 on your new remote to ensure it can operate the door.



WARNING!

This product may contain a coin/button cell battery. Keep product and batteries away from children. Battery can cause severe or fatal injuries in 2 hours or less if swallowed or placed inside any part of the body. Seek immediate medical attention if it is suspected that a coin/button battery has been swallowed or placed inside of any part of the body.



Documents / Resources



Remote Pro GDS800 Gate Upgrade Receiver Kit [pdf] Instructions GDS800 Gate Upgrade Receiver Kit, GDS800, Gate Upgrade Receiver Kit, Upgrade Receiver Kit, Receiver Kit, Kit

References

- R Garage Door Remotes | Car Remotes | Free Shipping AU Wide Remote Pro
- R Garage Door Remotes | Car Remotes | Free Shipping AU Wide Remote Pro
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.