



Remote Tech RT-AC34B Electronic Key User Manual

[Home](#) » [Remote Tech](#) » Remote Tech RT-AC34B Electronic Key User Manual 

Remote Tech RT-AC34B Electronic Key User Manual



This remote has lock, unlock, Trunk, Left/right Doors button and panic buttons; you can lock and unlock the vehicle doors and trunk/hatch with the remote transmitter.

LOCK Button:

When you press the LOCK button, it locks all the doors.

Once:

Some exterior lights flash, all the doors and fuel fill door lock, and the security system sets.

Twice:(within five seconds after the first push):

Some exterior lights flash, the beeper sounds and verifies the security system is set.

UNLOCK Button:

Pressing the button unlocks the driver's door. Pressing the button again within 5 seconds unlocks the other doors.

Once:

Some exterior lights flash twice, and the driver's door and fuel fill door unlocks

Twice:

Some exterior lights flash twice, and the remaining doors unlock.

TRUNK Button:

Press the trunk release button for approximately one second to unlock and open the trunk

PANIC Button:

When you press the PANIC button, the vehicle will start sounding the horn and flashing the hazard lamp. To stop the alarm, press any button on the electronic key.

If you press the panic button for approximately one second, the following will occur for about 30 seconds:

The horn sounds.

Some exterior lights flash

Canceling Panic Mode

Press any button on the remote transmitter and set the power mode to ON

LEFT/RIGHT Doors Buttons:

Pressing either LEFT or RIGHT door buttons twice within five seconds on the remote opens and closes the corresponding sliding doors in the van.

Contents

[1 REMOTE START Button:](#)

[2 FCC COMPLIANCE
STATEMENT:](#)

[3 IC WARNING:](#)

[4 Documents / Resources](#)

[5 Related Posts](#)

REMOTE START Button:

Press the remote start button twice within 5 seconds. The vehicle will stay in the Remote Start mode for a 15-minute cycle. Press and release remote start button once to exit Remote Start mode.

FCC COMPLIANCE STATEMENT:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

IC WARNING:

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device

FCC ID: 2AOKM-HON-V5

P/N: RT-4301N, RT-4311N

[Remote Tech RT-AC34B Electronic Key \[pdf\] User Manual](#)

RT-AC34B, RT-AC35B, RT-AC34B Electronic Key, Electronic Key, Key