Manuals+ — User Manuals Simplified.

Remote Tech RT-CY7BT Remote Key User Manual

Contents

Remote Tech RT-CY7BT Remote Key

1. **key:** Unlock key
2. **key** Lock key
3. **key:** Start key
4. **key:** trunk
5. **key:** Panicky, used to looking for car
6. **key:** Left sliding door
7. **key:** Right sliding door

Company: Remote Tech LLC
Address: 310 ALDER RD, Dover, DE 19904,USA
Name: Remote Key
Model: RT-CY7BT

Operation instructions

1. After matching the key to the car, press 1 the unlock key for 2 seconds to open the door and press 2 the lock key for 2 seconds to close the door.
2. The ignition start key is used to manually unlock and start the car.

Product parameters

Rated voltage	DC 3V
Working current	<6mA
Operating voltage	1.8V~3.6V
Transmit power	>-20dbm
Key operation force	400±50g
Operating temperature	-5°C +45°C
Stand-by current	<1uA
transmitting frequency	433.92M±75KHZ
Modulation	ASK
Battery	CR2032
Key durability	More than 100,000 times

User manual

FCC COMPLIANCE STATEMENT:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

IC WARNING

This device contains license-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's license-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

Documents / Resources

[**Remote Tech RT-CY7BT Remote Key**](#) [pdf] User Manual
CYV12, 2AOKM-CYV12, 2AOKMCYV12, RT-CY7BT Remote Key, RT-CY7BT, Remote Key