Manuals+ — User Manuals Simplified.

Remote Tech RT-HK7F20 Electronic Key

Remote Tech RT-HK7F20 Electronic Key User Manual

Contents

Remote Tech RT-HK7F20 Electronic Key

Specifications

- **FCC ID**: 2AOKM-HK24
- **IC:** 24223-HK24
- **MODEL:** RT-HK7F20 RT-HK4F20
- **PART NUMBER:** RT-M5000 RT-M5300

This remote has lock, unlock, Liftgate Unlock Hold Button, Forward button and Backward button, remote start Button, and panic hold buttons; you can lock and unlock the vehicle doors and trunk/hatch with the remote transmitter.

USING INSTRUCTION

LOCK Button
When you press the LOCK button, it locks all the doors.

UNLOCK Button
Pressing the button unlocks the driver's door. Pressing the button again within 5 seconds unlocks the other doors.

Liftgate Unlock Hold Button
Press and Hold. Will open if equipped with a power liftgate

PANIC HOLD Button
When you press the PANIC button, the vehicle will start sounding the horn and flushing the hazard lamp. To stop the alarm, press any button on the electronic key.

Forward button and Backward button
When using the Remote Forward/ Backward function, the vehicle moves in the direction of the button while the button is pressed.

REMOTE START Button
Press the remote start button twice within 5 seconds. The vehicle will stay in the Remote Start mode for a 15-minute cycle. Press and release the remote start button once to exit Remote Start mode.

FCC COMPLIANCE STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

IC WARNING

This device contains license-exempt transmitter(s)/receiver(s) that comply with Innovation, Science ,and Economic Development Canada's license-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device

FAQ

Q: How do I know if my vehicle is equipped with a power liftgate?
A: Check your vehicle's specifications or consult your vehicle manual for information on whether it has a power liftgate feature.

Q: Can I program additional functions to the remote key?
A: The remote key's functions are pre-programmed and cannot be altered or customized.

Documents / Resources

Remote Tech RT-HK7F20 Electronic Key [pdf] User Manual
RT-HK7F20 Electronic Key, RT-HK7F20, Electronic Key, Key

References

- **User Manual**