



Remote Tech RT-J54T5 Remote Key User Manual

[Home](#) » [Remote Tech](#) » Remote Tech RT-J54T5 Remote Key User Manual 

Remote Tech RT-J54T5 Remote Key User Manual

Contents

- [1 Product Description](#)
- [2 Specification](#)
- [3 Operation instructions](#)
- [4 Product parameters](#)
- [5 FCC COMPLIANCE STATEMENT](#)
- [6 Documents / Resources](#)
- [7 Related Posts](#)

Product Description



1 key:Unlock key

2 key: Lock key

3key: Start

4 key: Panic

5 key Trunk

Specification

Company: Remote Tech LLC

Address: 310 ALDER RD, Dover, DE 19904, USA

Name: Remote Key

Model: RT-J54T5, RT-J54T4, RT-J54T3, RT-R54T8, RT-R54T9

Operation instructions

1. After matching the key to the car, press 1 the unlock key for 2 seconds to open the door and press 2 the lock key for 2 seconds to close the door.
2. The Start key is used to manually unlock and start the car.

Product parameters

Rated voltage	DC 3V
Working current	<5mA
Operating voltage	1.8V~3.6V
Transmit power	>-20dbm
Key operation force	200±50g
Operating temperature	-5°C +45°C
Stand-by current	<1uA
transmitting frequency	433.92M±75KHZ
Modulation	ASK
Battery	CR2032
Key durability	More than 100,000 times

FCC COMPLIANCE STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

IC WARNING

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device

Documents / Resources



[Remote Tech RT-J54T5 Remote Key](#) [pdf] User Manual
CYV13, 2AOKM-CYV13, 2AOKMCYV13, RT-J54T5, RT-J54T4, RT-J54T3, RT-R54T8, RT-J54T5 Remote Key, RT-J54T5, Remote Key, RT-R54T9