



# Remote Tech RT-N018 Electronic Key User Manual

[Home](#) » [Remote Tech](#) » Remote Tech RT-N018 Electronic Key User Manual 



## Contents

- [1 Remote Tech RT-N018 Electronic Key](#)
- [2 FCC COMPLIANCE STATEMENT:](#)
- [3 Documents / Resources](#)
- [4 Related Posts](#)

## Remote Tech RT-N018 Electronic Key



This remote has lock, unlock, trunk, and panic buttons; you can lock or unlock the vehicle doors and trunk with the remote transmitter.

- **LOCK Button:**

When you press the LOCK button, it locks all the doors.

- **UNLOCK Button:**

Pressing the button unlocks the driver's door. Pressing the button again within 5 seconds unlocks the other doors.

- **TRUNK Button:**

Pressing the button opens and closes the trunk.

- **PANIC Button:**

When you press the PANIC button, the vehicle will start sounding the horn and flashing the hazard lamp. To stop the alarm, press any button on the electronic key.

## FCC COMPLIANCE STATEMENT:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:


- 1. This device may not cause harmful interference, and
  - 2. this device must accept any interference received, including interference that may cause undesired operation.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**IC WARNING:**

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- 1. This device may not cause interference.
- 2. This device must accept any interference, including interference that may cause undesired operation of the device

**Documents / Resources**

	<p><a href="#">Remote Tech RT-N018 Electronic Key [pdf]</a> User Manual NI8, 2AOKM-NI8, 2AOKMNI8, RT-N018 Electronic Key, Electronic Key</p>
--	--