



Remote Tech RT-NIEW8 Electronic Key User Manual

[Home](#) » [Remote Tech](#) » Remote Tech RT-NIEW8 Electronic Key User Manual 

Remote Tech RT-NIEW8 Electronic Key User Manual



Contents

- [1 Instructions](#)
- [2 FCC COMPLIANCE STATEMENT:](#)
- [3 Documents / Resources](#)
- [4 Related Posts](#)

Instructions

This remote has lock, unlock, trunk, and panic buttons; you can lock or unlock the vehicle doors and trunk with the remote transmitter.

LOCK Button:

When you press the LOCK button, it locks all the doors.

UNLOCK Button:

Pressing the button unlocks the driver's door. Pressing the button again within 5 seconds unlocks the other doors.

TRUNK Button:

Pressing the button opens and closes the trunk.

PANIC Button:

When you press the PANIC button, the vehicle will start sounding the horn and flashing the hazard lamp. To stop the alarm, press any button on the electronic key.

FCC COMPLIANCE STATEMENT:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.


Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

IC WARNING:

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

Documents / Resources

	<p>Remote Tech RT-NIEW8 Electronic Key [pdf] User Manual NI12, 2AOKM-NI12, 2AOKMNI12, RT-NIEW8, Electronic Key</p>
---	--