



Remote Tech VL1 Keyless Transmitter User Manual

[Home](#) » [Remote Tech](#) » Remote Tech VL1 Keyless Transmitter User Manual 

Remote

User's manual

This remote has a lock, unlocking the left door, right door, panic, trunk buttons, you can open or close the vehicle with the remote transmitter.

LOCK

When you press the LOCK button, the vehicle doors will lock. If the door is not closed, can not lock the door, also the key in the ignition switch also can not lock the doors.

UNLOCK

When you press the UNLOCK button, you can open the all doors. if the key is in the ignition switch, can not unlock the doors.

LIGHT

When you press the LIGHT button, you can turn on or turn off the lamp.

Trunk

When press the TRUNK buttons, open the trunk. It can not close the trunk using this transmitter.

PANIC

When pressing the PANIC button, the vehicle will start sounding the horn and flushing the hazard lamp until presses any buttons on the transmitter.

Contents

[1 FCC COMPLIANCE](#)

[STATEMENT:](#)

[2 IC WARNING:](#)

[3 Documents / Resources](#)

[4 Related Posts](#)

FCC COMPLIANCE STATEMENT:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including

interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

IC WARNING:

This device contains license-exempt transmitter(s)/receiver(s) that comply with Innovation, Science, and Economic Development Canada's license-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference. (2) This device must accept any interference, including interference that may cause undesired operation of the device

FCC ID: 2AOKM-VL1

IC: 24223-VL1

MODEL: RT-VL15B

Documents / Resources