



RemotePro Coding HT3 Remote to Motor Instructions


[Home](#) » [RemotePro](#) » RemotePro Coding HT3 Remote to Motor Instructions 

Contents

- [1 RemotePro Coding HT3 Remote to Motor](#)
- [2 Documents / Resources](#)
- [3 Related Posts](#)



RemotePro Coding HT3 Remote to Motor



1. Remove the face plate of the motor to locate the radio set button.
2. The radio set button is generally yellow but the colour may vary depending on your motor model.
3. Press the radio set button on your motor once and release.
4. A light will illuminate on your motor.
5. Press and hold the button on the new remote which you wish to operate the motor until the light on the motor goes out.
6. Your remote is now programmed. Please push the button on the remote to test. www.remotepro.com.au

WARNING

To prevent possible **SERIOUS INJURY** or **DEATH**:

- Battery is hazardous: **NEVER** allow children near batteries.
- If battery is swallowed, immediately notify a doctor.

To reduce risk of fire, explosion or chemical burn:

- Replace **ONLY** with the same size and type battery
 - **DO NOT** recharge, disassemble, heat above 100° C or incinerate
- Battery will cause **SEVERE** or **FATAL** injuries in 2 hours or less if swallowed or placed inside any part of the body.



Documents / Resources

	<p>RemotePro Coding HT3 Remote to Motor [pdf] Instructions RemotePro, Coding, HT3, Remote to Motor</p>
--	--