



## remotepro M802 Garage Remote Programming Instructions

[Home](#) » [RemotePro](#) » remotepro M802 Garage Remote Programming Instructions 

# RemotePro

M802 Garage Remote Programming  
Instructions



## Contents

- [1 Coding Instructions](#)
- [2 WARNING](#)
- [3 Documents / Resources](#)
- [3.1 References](#)
- [4 Related Posts](#)

## Coding Instructions

1. Open the original working remote (which may be located under the battery cover or you may need to remove the screws at the back of the remote). Please note: If you do not have an original remote you will need to locate the DIP switches on the motor or receiver.
2. Open the new remote (may be located under the battery cover or you may need to remove the screws at the back of the remote).
3. Change the DIP switches in the new remote, by moving these up or down to match the switches in either your old remote or your motor.
4. Close the remotes and test.

## WARNING



**To prevent possible SERIOUS INJURY or DEATH:**

- Battery is hazardous: NEVER allow children near batteries.
- If the battery is swallowed, immediately notify a doctor.

**To reduce the risk of fire, explosion, or chemical burn:**


- Replace ONLY with the same size and type of battery
- DO NOT recharge, disassemble, heat above 100° C, or incinerate

The battery will cause SEVERE or FATAL injuries in 2 hours or less if swallowed or placed inside any part of the body.

# RemotePro

[www.remotepro.com.au](http://www.remotepro.com.au)

## Documents / Resources

	<a href="#">remotepro M802 Garage Remote Programming</a> [pdf] Instructions M802 Garage Remote Programming, Garage Remote Programming, Remote Programming
---	--

## References

- [R Garage Door Remotes | Car Remotes | Free Shipping AU Wide – Remote Pro](#)

