



RETEKESS TR630 CD and Cassette Player Combo User Manual

[Home](#) » [RETEKESS](#) » RETEKESS TR630 CD and Cassette Player Combo User Manual 

Contents

- [1 RETEKESS TR630 CD and Cassette Player Combo](#)
- [2 Product Information](#)
 - [2.1 Specifications](#)
- [3 Product Usage Instructions](#)
- [4 Documents / Resources](#)
 - [4.1 References](#)



RETEKESS TR630 CD and Cassette Player Combo



Product Information

Specifications

- **Model:** Reteless TR630CD and Cassette Player Combo
- **Recording Formats:** Tape to USB or SD card
- **Radio Recording:** Yes, from radio to U-drive

Product Usage Instructions

Section 1: Playback and Auto Shutdown

To play Dota, follow these steps:

1. Connect the Reteless TR630CD and Cassette Player Combo to a power source.
2. Turn on the device using the power button.
3. Choose the playback option from the menu.
4. If you want to repeat the playback, select the repeat option. If not, the playback will stop automatically when it is over.

Section 2: Recording Audio

To record audio from tape to a USB or SD card, follow these steps:

1. Connect a USB or SD card to the Reteless TR630CD and Cassette Player Combo.
2. Insert the tape that you want to record from into the player.
3. Select the recording option from the menu.
4. Choose the destination as a USB or SD card.

5. Start the recording process.

Section 3: Radio Recording

To record audio from radio to a U-drive, follow these steps:

1. Tune in to the desired radio station using the Reteless TR630 radio.
2. Connect a U-drive to the Reteless TR630 radio.
3. Select the radio recording option from the menu.
4. Choose the destination as U-drive.
5. Start the recording process.

when done playing do tapes shut off automatically?

You can choose whether you want to repeat the playback if you don't choose to repeat the playback it will stop when the playback is over


Can you record audio from tape to usb or sd card?

Yes The Reteless TR630 CD and Cassette Player Combo can record audio from tape to a USB or SD card.

Can it record from radio to mp3/u-drive?

The Reteless TR630 radio can record from radio to u-drive

Documents / Resources

	RETELESS TR630 CD and Cassette Player Combo [pdf] User Manual TR630 CD and Cassette Player Combo, TR630, CD and Cassette Player Combo, Cassette Player Combo, Player Combo, Combo
---	--

References

- [User Manual](#)