



# RETROFLAG Xbox Series Controllers SuperPack Instruction Manual

[Home](#) » [RETROFLAG](#) » RETROFLAG Xbox Series Controllers SuperPack Instruction Manual 

## Contents

- [1 RETROFLAG Xbox Series Controllers SuperPack](#)
- [2 OVERVIEW](#)
- [3 Product features](#)
- [4 INSTALLATION](#)
- [5 Charging LED Status](#)
- [6 Mode Switch](#)
- [7 Basic Manipulation](#)
- [8 Macro Settings](#)
- [9 Documents / Resources](#)



## RETROFLAG Xbox Series Controllers SuperPack

RETROFLAG-Xbox-Series-Controllers--SuperPack-product.

## OVERVIEW

RETROFLAG-Xbox-Series-Controllers--SuperPack-fig- (1)

## Product features

1. Makes the Xbox Series Controller compatible with the Nintendo Switch with motion sensing and wake-up function.
2. Turn the Xbox Series Controller into an Elite Pro Controller for PC with back buttons.
3. Last up to 8 hours with a build-in 1000mAh high capacity lithium battery pack.

## INSTALLATION

RETROFLAG-Xbox-Series-Controllers--SuperPack-fig- (3)

RETROFLAG-Xbox-Series-Controllers--SuperPack-fig- (4)

### Charging LED Status

- **Red LED slowly blinking** —> Charging
- **Red LED stays solid** —> Charging complete
- **Red LED quickly blinking** —> Low battery
- **Charging** time: Maximum 4 hours

### Mode Switch

- When it's on I • ] position, the Super Battery Case is only for charging and does not change the default settings of the controller.
- When it's on I SI position, turn the Xbox Series Controller into a Switch Pro controller.
- When it's on IX] position, turn the Xbox Series Controller into an Elite Pro Controller for PC.

### Bluetooth Pairing

Hold the I '8'] button until the green LED rapidly blinking, Bluetooth pairing begins.

### Power off

- When it's on I [ ] position, the Super Battery Case turns off its power.
- The controller will go into the sleep mode when there is no operation detected, press I ' [ ] button to restart and reconnect the controller.

### Basic Manipulation

- Turbo/ Auto
- Turbo: Press the Fn + other button to activate
- Auto: Press the Fn button twice + other button to activate
- Turbo speed: Press Fn + right joystick up/down to adjust the turbo speed among slow, medium and fast.
- Turbo off: Double press the Fn button to turn off all the Turbos. (The available buttons for Turbo: A/B/X/Y/LB/RB/LT/RT/LS/ Co/= )
- You can adjust the turbo speed for each separate button in the App.

### Macro Settings

- **Macro recording**
  - Press Fn + ML/MR to record the macro, mode LED turns from green to blue.
- **Macro preservation**
  - Press ML/MR again to finish recording the macro, mode LED turns from blue to green.
- **Remove macro**

Hold Fn button, then press ML/MR twice to remove the macro.

- Macro recording supports up to 42 keystroke sequences.
- The macro parameters of each step can be manually fine-adjusted in the App.

- **Button mapping to ML/MR**

- Please refer to the instructions of macro recording & preservation above.

You can change the button mapping for other buttons in the App.

- **PC motion controls (replace the Right joystick)**

- Record the I ☐ I button to ML/MR. (Please check the Macro settings)
- Record the I , ☐ I button once, Keep holding the ML/MR button to activate the motion controls.
- Record the I , ☐ I button twice, press the ML/MR button to activate the motion controls, press again to deactivate.

## **Change the SuperPack settings with the app(Advanced Setting)**

Install the Keylinker App on your mobile phone or tablet. The App can modify more than 10 functional parameters of the controller, such as key mapping, vibration intensity, joystick sensitivity and trigger travel distance. The controller can be connected to both the gaming device and the app for setting, enabling adjustment while playing.

### **Software download and installation**

Search for “Keylinker” in the app store, then download and install.

### **Configuration center connection**

1. Run the Keylinker
2. Look for “SuperPack-XXXXXX” on the Bluetooth list of your device and choose to connect.
3. Click the gear icon to enter its configuration centre after the connection.

### **SuperPack reset**

- Keep holding the pairing button I ☐ I for about 10 seconds.
- The reset function does not delete the various setting information of the Super Battery Case.


### **Firmware upgrade**

Upgrade the Super Battery Case via the “Firmware upgrade” menu of the KeyLinker.

### **Motion controls calibration**

- Hold A+ I ☐ I button, then change the mode switch to I S I to activate the calibration function, the Blue LED flashes rapidly to indicate it's entering the calibration mode. Place the controller on the desk then press I ☐ I button to start the calibration. The setting will automatically completed and exit the mode after about 1 second.
- The horizontal calibration has been carried out before delivery, there is no need to perform this operation if there is no deviation.

## **Documents / Resources**



**[RETROFLAG Xbox Series Controllers SuperPack](#)** [pdf] Instruction Manual  
Xbox Series Controllers SuperPack, Xbox Series, Controllers SuperPack, SuperPack