



Retrotouch 02832 Smart Button Plate Instructions

[Home](#) » [Retrotouch](#) » Retrotouch 02832 Smart Button Plate Instructions 

Retrotouch®

Switches & Sockets
02832 Smart Button Plate
Instructions

SMART BUTTON SOLD SEPARATELY



Contents

[1 02832 Smart Button](#)

[Plate](#)


[2 Stick anywhere](#)

[3 Documents / Resources](#)

[4 Related Posts](#)

02832 Smart Button Plate

Stick anywhere



Clean & dry the surface you wish to stick the switch to. Use the 3M sticky pads and locate them on the back of the switch. Peel and Stick. Apply pressure for 10 seconds to get a firm fix.

Retrotouch®

Switches & Sockets
RETROTOUCH.CO.UK/BUTTON-PLATE

Documents / Resources



[Retrotouch 02832 Smart Button Plate](#) [pdf] Instructions
02832, Smart Button Plate, 02832 Smart Button Plate

