



Reverie R600/R650 Signal Frequency/Non-Bluetooth Remote Instructions

[Home](#) » [Reverie](#) » Reverie R600/R650 Signal Frequency/Non-Bluetooth Remote Instructions 



Pairing a Remote to a Power Base (Signal Frequency/Non-Bluetooth)

NOTE: The power base is paired to its remote upon delivery. If for some reason you should need to pair the two, follow these instructions.

Step 1

Place batteries into a remote control (3 x AAA batteries)



Step 2

Check that the power base is plugged into a functioning outlet.

Step 3

Press the learn button underneath the base (on the control box) for 3 seconds.



Step 4

When the button illuminates to green on the control box the radio frequency code setting function will be activated.

Step 5

Press any button on the remote control.

Step 6

When the receiver light flashes, you have completed the learning process of the radio frequency code.



NOTE: To join another power base to the same remote, repeat steps 1-6 with the other power base.

CUSTOMER SERVICE:

800-973-8374

CUSTOMERSERVICE@REVERIE.COM

Contents

[1 Documents / Resources](#)

[2 Related Posts](#)

Documents / Resources

	<p>Reverie R600/R650 Signal Frequency/Non-Bluetooth Remote [pdf] Instructions R600, R650, Signal Frequency Non-Bluetooth Remote</p>
--	---

