



Reverie RC-WM-119 Replacement Remote for Tempurpedic Ergo Advance User Guide

[Home](#) » [Reverie](#) » Reverie RC-WM-119 Replacement Remote for Tempurpedic Ergo Advance User Guide 

*Reverie RC-WM-119 Replacement Remote for
Tempurpedic Ergo Advance User Guide*

Thank you for being a Reverie customer! We appreciate you very much. Please follow these instructions to pair your new remote to your adjustable base.

Remote Replacement instructions for your Tempur Ergo remote. The remote you just received (RC-WM-119) is an updated version of your original remote (part RC-WM-101).



STEP 1 Place 3 AAA batteries into the remote.

STEP 2 Ensure the Ergo system is plugged into a functioning outlet.

STEP 3 Locate the emergency power down box under the Ergo system and lightly press the learn button for three (3) seconds.



STEP 4 When the Green LED light illuminates, the RF frequency code setting function will be activated.

Note: The LED light is located on the side of the plastic housing and is only visible when lit. If a new signal is not received, it will reset itself to normal mode in 10 seconds.

STEP 5 Press any button on the wireless remote control. The Green LED light will blink once it receives a remote signal.

Note: the bed will not respond for 10 seconds during the remote learn process.

STEP 6 When the Green LED light on the Emergency Power Down Box turns off, you have completed the learning process of the RF frequency code.

Note: Steps 4-6 need to be repeated 3 times to knock out the connection from your previous remote

- **To pair a second base to the same remote, repeat the same process above for the second base.**

If remote pairing has not worked or the remote fails to stay paired to the bed please contact us for further assistance:

warrantyrepair@reverie.com or 1-800-979-1457

1 Documents / Resources
2 Related Posts

[illegible]

Manuals+,