



REXING S1 Dash Cam 3-Channel Front User Guide

[Home](#) » [Rexing](#) » REXING S1 Dash Cam 3-Channel Front User Guide 



Contents

- [1 REXING S1 Dash Cam 3-Channel Front User Guide](#)
- [2 1. Overview](#)
- [3 2. What's in the box?](#)
- [4 3. Camera Overview](#)
- [5 4. Installation](#)
- [6 5. Basic Operation](#)
- [7 Warranty & Support](#)
- [8 Documents / Resources](#)
- [9 Related Posts](#)

REXING S1 Dash Cam 3-Channel Front User Guide



The information in this manual is subject to change without notice. Rexing All Rights Reserved

www.rexingusa.com

1. Overview

Thank you for choosing REXING!

We hope you love your new products as much as we do. If you need assistance, or have any suggestions to improve it, please contact us.

care@rexingusa.com

(877) 740-8004

Our support team will respond you as soon as possible.

Always a surprise in Rexing.

Check us out here

- <https://www.facebook.com/rexingusa/>
- <https://www.instagram.com/rexingdashcam/>
- <https://www.rexingusa.com/support/registration/>
- <https://www.rexingusa.com/support/product-support/>




2. What's in the box?




1



2



3




4




5



6



7




8



9


1. S1 Quick Start Guide
2. Safety Guide
3. USB Cable
4. 3M Adhesive Mount
5. cable Adhesive Spacer
6. Cable Management Tool
7. Rexing S1 Dashboard camera
8. Car Power Connector (12ft)
9. Rear camera and Rear camera cable

3. Camera Overview



1. Power Button
2. Menu Button | Mode Button
3. Left Navigation Button | Record Button
4. OK (Confirm) Button | Emergency Lock Button
5. Right Navigation Button | Screen Toggle Button | Hold to take photo
6. Front Camera
7. 4 IR Lights | Cabin camera
8. Power | USB Charging Port
9. Micro SD Card Slot
10. Rear Camera Port
11. Reset Button

Screen Icons




4. Installation

Step 1

Install the Dash Cam

Place the 3M tape on the mount and properly orient the mount square to the roof and hood line of the vehicle.

Firmly press the mount onto the windshield. Wait at least 20 minutes before mounting the camera. Orient the mount as shown on the illustration above.



Step 2

Insert the Memory Card


The Rexing S1 accepts [Class 10/UHS-1 or higher] Micro SD memory cards up to 256GB. You will need to insert a memory card before you can begin recording. Before inserting or removing a memory card, first ensure you've powered down the device. Gently push the memory card in until you hear a click, and allow the spring release to push the card out.




Step 3

Power the Camera and Format the Memory Card

Power the camera by connecting the charger to the car cigarette lighter and camera. To ensure the SI records to your memory card properly and without error. Before you start using a new memory card, you must format the card within the camera using the format function. Always backup important data stored on the memory card before formatting.



To format the memory card, make sure you have inserted your memory card, then turn on the device by connecting to a power source. Press Left Navigation Button to stop recording. Then press the MENU button twice to enter the System Setup Menu.



Press the Yea button ID confirm formatting the card

Use the RIGHT and LEFT navigation buttons and go to the Memory card setting. Press the OK button to confirm the selection. You may now disconnect from power. The camera will shut down after 3 seconds. The camera should begin recording automatically the next time it is powered on.

Step 4


Mount the Rear camera

Mount the rear camera as shown below. Use the provided rear camera cable to connect the rear camera to the front camera.

Plug the Rear Camera into the Dash Cam



Rear Camera Installation



Step 5

Installing the camera onto the Windshield

Place the camera on the mount and carefully route the power cable around the windshield and tuck it under the trim.

Plug the car charger cable to a 12V DC power outlet or the car cigarette lighter. Connect car charger to the camera. The camera will auto-start recording once it's powered on.

Connect the power cable to the dash cam



Plug Mini USB Connector to the dash cam



Plug charger into power outlet or cigarette lighter

5. Basic Operation

Device Power

The device will be automatically powered on when plugged into a 12V accessory socket or cigarette lighter when receives a charge (i.e.: the vehicle is started). To turn the device on manually, press and hold the Power button until the welcome screen appears.

The camera will automatically start recording when it's powered on.



Press and hold the Power button to turn the device on manually

Menu Settings

Power the camera On. If the camera is recording, press the Left Navigation button to stop recording.

Hold the MENU button and toggle to the desired mode. Press the MENU button once to enter the settings menu for a Mode. Press the MENU button twice to enter the System Settings (Set up). Hold the MENU button to exit settings.

Video Recording

The camera will automatically start recording when the device receives a charge. The LED lights and red dot will blink red device when recording. Press the Left Navigation button to stop recording.

Red dot will blink red device when recording



Video Playback


Playback of videos can be done on the device or a computer. To playback a video on the device, hold MENU button toggle to the Playback mode. Hold MENU button to Change the views. Use the Right and Left navigation buttons to toggle to the desired video. Press the OK button to play.



During playback, use the OK (pause), Left navigation (rewind) and Right navigation (fast forward) buttons to control the video playback. Hold OK Button to exit the current Mode.

To playback a video on the computer. either use an SD card adapter or connect the device to the computer directly using the USB cable.


To playback a video using an SD card adapter, remove the memory card and Insert It into an SD card adapter. Place the adapter in the computer. Then place the adapter into the computer.



To playback a video using USB cable, connect the USB Cable to the device and the computer. After the device is powered on, press the OK button to select MSDC.

On the computer, navigate to device drive. The videos are stored at the files. The locked videos are stored at:\Event.

Select the video to playback.



Connect USB connector to computer



Select MSDC

Taking Photos

Hold the Left navigation button to take a photo.

To view a photo, stop video recording and hold MENU button to toggle to the Playback Mode. Hold MENU button one more time to enter the Photo playback mode.

Press the Left and Right Navigation buttons to toggle through your photos.



To delete a photo, stop video recording and toggle to the Playback Mode and toggle through the videos and photos to the one you want to delete.



Hold the LEFT button to delete current video/photo.

Press the OK button to confirm delete.

Wi-Fi Connect

Download "Rexing Connect" app from the App Store/Google Play Store.

1. To access or exit the Wi-Fi feature, hold down the OK Button. Press Menu Button four times to find the wifi info.
2. Open Wi-Fi settings on your phone, find "SSID" from the list, tap to connect.
(Default password: 12345678)
3. Open the Rexing Connect app, tap "Recorder" to enter the real time video streaming page.



4. Once connected, the dash cam screen will switch to the camera view and will display “WIFI Connected” message. Using the Rexing Connect app, you can view a live preview of the dash cam screen, start/stop recording, as well as view and save your captures with your mobile device.

Warranty & Support

Warranty

The Rexing S1 Dash Cam comes with a full 12-month warranty. If you register your product on our official site (<https://www.rexingusa.com/support/registration>), you can extend the warranty to 18 months.

Support

If you have any questions regarding your product please do not hesitate to contact us at care@rexingusa.com, or call us at (877) 740-8004. Queries are typically answered within 12-24 hours.

Your opinion matters


Rexing is firmly committed to always improving our products, services, and user experience. If you have any thoughts on how we can do even better, we welcome your constructive feedback and suggestions.

Connect with us today at care@rexingusa.com

Thank you for choosing Rexing!

Read More About This Manual & Download PDF:

Documents / Resources



[REXING S1 Dash Cam 3-Channel Front](#) [pdf] User Guide
S1, 2AW5WS1, S1 Dash Cam 3-Channel Front, Dash Cam 3-Channel Front