

RICE LAKE 920i Programmable Weight Indicator and **Controller User Manual**

Home » RICE LAKE » RICE LAKE 920i Programmable Weight Indicator and Controller User Manual



Contents

- 1 RICE LAKE 920i Programmable Weight Indicator and
- 2 Standard Features
- 3 Documents / Resources
 - 3.1 References
- **4 Related Posts**



RICE LAKE 920i Programmable Weight Indicator and Controller



Standard Features

- Pre-programmed software to carry out specific weighing functions
- Utilize Rice Lake's iRite™ programming language
- For use with all Rice Lake 920i models (hardware requirements may apply)
- Available pre-installed with purchase of new equipment, or via iRev™ for installation on existing 920i models
- Fully customizable

Dual Kiosk Truck In/Out Single Scale

PN 156959:

System consists of a bidirectional single platform truck scale, inbound truck kiosk and outbound truck kiosk. Inbound (if two outbound kiosks are used) and outbound tickets with transaction storage of each weighment.

Suggested Hardware

- PN 119687 Inbound/Outbound kiosk
- PN 119689 A/D kiosk option

Grain Program with Shrink Calculator

PN 156886:

This custom application for the 920i supports weighing trucks of grain. Up to 200 grain types, associated divisors and accumulator can be stored. Up to 500 accounts and 1,000 trucks can be stored.

Suggested Hardware

- PN 67527 920 single channel A/D
- PN 67600 1M memory card
- PN 23113 Epson TM-U295 ticket printer

• PN 93359 PS2 keyboard

Part Number/Price

Part #	Description	Price
153146	Short axle weighing program	Consult
SZ99999	Truck in/out with report	Consult
77297	Truck in/out with products/customers/trucks and reports	Consult
156886	Grain program with shrink calculation	Consult
156959	Dual kiosk truck in/out single scale	Consult

Truck In/Out with Products/ Customers/Trucks and Reports PN 77297:

This program supports truck in/out weighing program for manual truck transactions using Rice Lake Weighing Systems' 920i digital weight indicator. Stored IDs allow you to keep a database of truck IDs, customer, product, project information and weigh-in weights in the indicator's memory. Parameters are accessed by simply scrolling through the Supervisor main menu using the down arrow on the 920i. The 920i can automatically store up to 100 truck IDs and tare weights, 950 customers, 1,000 products and 1,000 projects.

Suggested Hardware

- PN 67527 920 single channel A/D
- PN 67600 1 MB memory card
- PN 23113 Epson TM-U295 ticket printer
- PN 93359 PS/2 keyboard

Short Axle Weighing Program

PN 153146:

920i custom program will interface to a short axle scale and direct each axle across the scale using traffic lights.

Suggested Hardware

- PN 67527 920 single channel A/D
- PN 23113 Epson TM-U295 ticket printer
- PN 101923 FRP box with 4 channel relay rack, for traffic light control
- PN 23146 Traffic light kit
- PN 15971 AC output relays for above (2 needed)
- PN 103181 LaserLight remote display (optional)
- PN 167093 LaserLight 2 remote display (optional)

Truck In/Out with Report

PN SZ99999:

920i program allows trucks to weigh in and out (saves inbound weight after weighing out and has value swapping) and stores the transaction after each weigh out with truck ID, gross, tare and net. Transactions may be printed or cleared at any time through the Setup menu. An HID scanner is available as a peripheral piece of hardware.

Suggested Hardware

- PN 119687 Outbound kiosk
- PN 119689 A/D kiosk option
- PN 119743 HID kiosk option

An ISO 9001:2015 Accredited Company © 2023 Rice Lake Weighing Systems 1/23 Prices and specifications subject to change without notice. Visit <u>ricelake.com</u> for current prices.

Webside: www.ricelake.com

Phone: 800-472-6703

Documents / Resources



RICE LAKE 920i Programmable Weight Indicator and Controller [pdf] User Manual 920i Programmable Weight Indicator and Controller, 920i, Programmable Weight Indicator and Controller, Weight Indicator, Indicator, Controller

References

• Rice Lake Weighing Systems

Manuals+,