

**RICOH
GR III HDF,
GR IIIx HDF
Diffusion
Filter**



RICOH GR III HDF, GR IIIx HDF Diffusion Filter User Guide

[Home](#) » [RICOH](#) » RICOH GR III HDF, GR IIIx HDF Diffusion Filter User Guide 

Contents

- [1 RICOH GR III HDF, GR IIIx HDF Diffusion Filter](#)
- [2 Specifications](#)
- [3 Button Name and Function](#)
- [4 Setting from the Menu](#)
- [5 Setting with the Fn Button](#)
- [6 FAQ](#)
- [7 Documents / Resources](#)
 - [7.1 References](#)

RICOH

RICOH GR III HDF, GR IIIx HDF Diffusion Filter



Specifications


- **Model:** RICOH GR III HDF (R02010), RICOH GR IIIx HDF (R05010)
- Built-in Highlight Diffusion Filter (HDF)
- Diffuses light and reduces screen contrast
- ND filter not installed also shown in playback mode for images taken with HDF ON.

The RICOH GR III HDF and RICOH GR IIIx HDF have a built-in “Highlight Diffusion Filter” (HDF) that diffuses light and reducing the contrast of the entire screen.

The “ND filter” built into the standard model is not installed.


Button Name and Function

“HDF” is printed on the upper side near the Fn button (h) on the back of the camera.



Setting from the Menu

The HDF can be turned ON and OFF in [HDF] of the  4 menu. (Default setting: OFF)




[HDF] is supported by [Memory] of the D2 menu. The [HDF] setting is retained even after the camera is turned OFF and back ON.


If you do not want the setting to be retained when the camera is turned OFF, change the [Memory] setting. For more information on [Memory], refer to the FAQ page on the Ricoh website.

Setting with the Fn Button

The HDF can be turned ON by pressing FN h in the shooting mode. It is turned OFF when FN is pressed again. (Default setting: OFF)




The function of FN can be changed in [Fn Button Setting] of the C2 menu. [HDF] is set by default.



Display on the Monitor

The HDF icon is displayed when the HDF is ON in the shooting mode.



For images shot with the HDF set to ON, the HDF icon is displayed in the detailed information display in the playback mode.

<https://www.ricoh-imaging.co.jp/japan/support/>

FAQ

- **Q: How do I enable the HDF setting?**

- **A:** You can enable HDF by accessing the A4 menu and turning on the [HDF] setting. Press the h button in shooting mode to activate HDF.


- **Q: Can I change the HDF setting retention behavior?**

- **A:** Yes, you can adjust the [Memory] setting in the D2 menu to control HDF setting retention upon power cycle.

- **Q: Where can I find more information about HDF and other settings?**

- **A:** For additional information, refer to the FAQ page on the Ricoh website: [RicoSupport](#)

Documents / Resources



[RICOH GR III HDF, GR IIIx HDF Diffusion Filter](#) [pdf] User Guide

GR III HDF GR IIIx HDF Diffusion Filter, GR III HDF Diffusion Filter, GR IIIx HDF Diffusion Filter, GR III HDF, GR IIIx HDF, Diffusion Filter, Filter

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.